

# KANGOO Z.E.

vehicle user manual





# Welcome to your new vehicle



---


**This Driver's Handbook** contains the information necessary:

- for you to familiarise yourself with your vehicle, to use it to its best advantage and to benefit fully from all the functions and the technical developments it incorporates.
- to ensure that it always gives the best performance by following the simple, but comprehensive advice concerning regular maintenance.
- to enable you to deal quickly with minor faults not requiring specialist attention.

It is well worth taking a few minutes to read this handbook to familiarise yourself with the information and guidelines it contains about the vehicle and its functions and new features. If certain points are still unclear, our Network technicians will be only too pleased to provide you with any additional information.

The following symbols will help you when reading this manual:

 and  These appear in the vehicle and indicate that you should consult the manual for detailed information and/or limits on operations with respect to your vehicle's equipment.

 anywhere in the manual indicates a hazard, danger or a safety recommendation.

The descriptions of the models given in this handbook are based on the technical specifications at the time of writing. **This handbook covers all items of equipment** (both standard and optional) **available for these models but whether or not these are fitted to the vehicle depends on the version, options selected and the country where the vehicle is sold.**

**This handbook may also contain information about items of equipment to be introduced later in the model year. The diagrams in the user manual are provided as examples only.**

Enjoy driving your new vehicle.

Translated from French. Copying or translation, in part or in full, is forbidden unless prior written permission has been obtained from the vehicle manufacturer.



# C O N T E N T S

## Sections

**Getting to know your vehicle** .....

**1**

**Driving** .....

**2**

**Your comfort** .....

**3**

**Maintenance** .....

**4**

**Practical advice** .....

**5**

**Technical specifications** .....

**6**

**Alphabetical index** .....

**7**




# ***Section 1: Getting to know your vehicle***

Electric vehicle: introduction . . . . .	1.2
Important recommendations . . . . .	1.8
Electric vehicle: charging. . . . .	1.9
Key, radio frequency remote control: general information, use, deadlocking . . . . .	1.19
Opening and closing the doors . . . . .	1.24
Automatic locking when driving . . . . .	1.30
Headrests/Front seats . . . . .	1.31
Front seats. . . . .	1.34
Swivelling partition. . . . .	1.36
Seat belts. . . . .	1.37
Methods of restraint in addition to the front seat belts. . . . .	1.41
Side protection devices . . . . .	1.46
Additional methods of restraint . . . . .	1.47
Child safety: general information. . . . .	1.48
Choosing a child seat mounting. . . . .	1.51
Fitting a child seat . . . . .	1.54
Deactivating/activating the front passenger airbag . . . . .	1.63
Driving position . . . . .	1.66
Steering wheel/Power-assisted steering . . . . .	1.70
Warning lights . . . . .	1.71
Displays and indicators . . . . .	1.74
Trip computer . . . . .	1.77
Clock and outdoor temperature. . . . .	1.86
Rear view mirrors . . . . .	1.87
Audible and visual signals. . . . .	1.88
External lighting and signals . . . . .	1.89
Headlight beam adjustment. . . . .	1.92
Washers, wipers . . . . .	1.94
Additional heating tank . . . . .	1.97

## ELECTRIC VEHICLE: introduction (1/6)

42519






## ELECTRIC VEHICLE: introduction (2/6)

Electric vehicles have special features, but operate in a similar manner to conventional vehicles.

The main difference in electric vehicles is the exclusive use of electric energy instead of fuel, as used in conventional vehicles.

We therefore recommend that you read these instructions describing your electric vehicle carefully.



### Connected services

(depending on vehicle)

Your electric vehicle has connected services that provide information and/or control:

- your vehicle's charging status;
- the traction battery charging programming, based on certain choices on offer;
- air-conditioning remote programming (please see the information on "Air-conditioning: remote activation" in Section 3);
- ...

You can access these services by:

- external digital devices (mobile telephones **8**, tablets **9** etc.) ;
- multimedia screen **7**.

For more information, refer to the multimedia equipment instructions or contact an Approved Dealer.

You can subscribe to a connected service or extend it at any time by consulting an authorised dealer.

# ELECTRIC VEHICLE: introduction (3/6)

## Batteries

Your electric vehicle has two types of battery:

- a 400V traction battery;
- a standard 12V battery, identical to the one used in conventional vehicles.

## Traction battery

This battery stores the energy necessary to operate the motor in your electric vehicle properly. As with any battery, it discharges after use, and must be regularly recharged.

You do not have to wait until the traction battery hits the reserve level in order to recharge it.


Battery charging times vary depending on the type of specific wall unit socket or public terminal you connect to.

Your vehicle range will depend on the charge level of the traction battery, and also on your driving style, the outdoor temperature and the type of road.

Please refer to information on “Vehicle range: recommendations” in Section 2.


## 12 volt battery

The second battery, which on your vehicle is a 12 V battery comparable to that used in vehicles with combustion engines, supplies the energy required to operate vehicle equipment (lights, windscreen wipers, braking assistance etc.).




33436

The **A** symbol identifies the electrical elements in your vehicle which may present health risks.



## 400 volt electrical circuit

The 400V electrical circuit can be recognised by the orange **4** cables and by the elements signalled using the  symbol.



The vehicle's electrical system uses a voltage of approximately 400 volts.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels stuck onto the vehicle.

All interventions or modifications to the 400V electrical system (components, cables, connectors, traction battery) are strictly prohibited due to the risks they present to your safety. Please contact an authorised dealer.

**The risk of serious burns or electric shocks can lead to death.**

# ELECTRIC VEHICLE: introduction (5/6)

## Driving

As with a vehicle fitted with an automatic gearbox, you will have to get used to not using your left foot, and not using this foot to brake.

When driving, if you lift your foot off the accelerator pedal or depress the brake pedal, the motor generates electrical current during deceleration, and this energy is used to brake the vehicle and recharge the traction battery. Please refer to the information on the “Charge meter” in Section 2.

## Special conditions

After a maximum charge of the battery and during the first few miles of using the vehicle, the engine brake will be temporarily reduced. Please adapt your driving style appropriately.



The engine brake should under no circumstances be used as a substitute for the brake pedal.

Bad weather, flooded roads:



Do not drive through floods if the depth of water is above the lower edge of the wheel rims.



### Obstructions to the driver

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.

**There is a risk of wedging the pedals**

## ELECTRIC VEHICLE: introduction (6/6)

### Noise

Electric vehicles are particularly quiet. You will not yet necessarily be used to it, and neither will other road users. It is difficult for them to hear the vehicle when it is moving.

As the motor is silent, you will hear noises that you are not used to hearing (aerodynamic noises, tyre noise, etc.)

Each time the ignition is switched off, the ventilation will be switched off after about ten seconds.

### Pedestrian horn

The pedestrian horn enables you to warn others of your presence – especially pedestrians and cyclists.

When the engine is started, the pedestrian horn is activated automatically. The sound is triggered when the vehicle speed is between about 1 and 19 mph (1 and 30 km/h).



If a fault with the pedestrian horn is detected, the **10** warning light flashes. Consult an approved dealer.



Your electric vehicle is silent, so when you get out, always check that the gear selector is on **P**, engage the handbrake and switch off the ignition.

**RISK OF SERIOUS INJURY**

# IMPORTANT RECOMMENDATIONS



Please read these instructions carefully. Failure to follow these instructions may lead to a **risk of fire, serious injury or electric shock which may present a risk to life.**

## **In the event of an accident or impact**

In the event of an accident or an impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture), this may damage the electric circuit or the traction battery.

Have the vehicle checked by an authorised dealer.

Never touch the “400 volt” components or orange cables which are exposed and visible inside or outside the vehicle.

In the event of serious damage to the traction battery, leaks may occur:

- never touch the liquids (fluids, etc.) coming from the traction battery;
- in the event of contact with the body, wash the affected area with plenty of water and consult a doctor as soon as possible.

In the event of an impact, even slight, against the charging flap and/or valve, have them checked by an authorised dealer as soon as possible.

## **In the event of fire**

In the event of fire, make everyone evacuate the vehicle immediately and contact the emergency services, informing them that this is an electric vehicle.

Only use extinguishing agents ABC or BC that are permitted for use with electrical fires. Do not use water or other extinguishing agents.

In the event of damage to the electrical circuit, please call an authorised dealer.

## **All towing operations**

Please refer to the information on “Towing, breakdowns” in Section 5.

## **Washing the vehicle**

Never wash the engine compartment, the charging connection or the traction battery with a high-pressure jet.


This risks damaging the electric circuit.

Never wash the vehicle while it is charging.

**Risk of electric shock and a risk to life.**

## ELECTRIC VEHICLE: charging (1/10)

42520



### Charging schematic diagram

- 1 Specific wall socket or charging terminal
- 2 Charging cable
- 3 Electric charging connection

If you have any questions regarding the equipment needed for charging, please ask an authorised dealer.

## ELECTRIC VEHICLE: charging (2/10)



### **Important recommendations for charging your vehicle**

Please read these instructions carefully. Failure to follow these instructions may lead to **a risk of fire, serious injury or electric shocks which could result in death.**

### **Charging**

Do not do anything to the vehicle during charging (washing, working in the engine compartment, etc.).

In the event of the presence of water, signs of corrosion or foreign bodies in the charging cord connector or in the vehicle charging socket, do not charge the vehicle. Fire hazard.

Do not attempt to touch the cord contacts, the domestic socket or the vehicle charging socket, or introduce objects into them.

Never plug the charging cord into an adapter, multiple socket or extension lead.

The use of generators is prohibited.

Do not remove or change the vehicle charging socket or the charging cord. Fire hazard.

Do not modify or perform any action on the installation during charging.

In the event of an impact, even slight, against the charging socket or valve, have them checked by an authorised dealer as soon as possible.

Take care of the cord: do not tread on it, immerse it in water or pull on it or let anything knock against it.

Check regularly that the charging lead is in good condition.

In the event of damage to the charging lead (corrosion, browning, cuts, etc.), to the unit or to the vehicle's electrical charging socket, do not use them. Please see an authorised dealer to replace them.

In the event of non-activation of the charging flap locking mechanism and/or unlocking of the vehicle's electric charging socket, please contact an approved dealer.



# ELECTRIC VEHICLE: charging (3/10)




35907

## Charging cable A

This lead is specific to your vehicle and designed for connecting to wall sockets or public terminals to enable standard charging of the traction battery.

We recommend that you use a charging cord that enables a standard charge to charge the traction battery.

Each charging lead is stored in the luggage compartment of the vehicle.




42539

## Charging cable B

This cord allows:

- standard charge, on a socket used only for the vehicle (14 A charge);
- occasional charge using a domestic socket, (10 A charge) when you are not at home, for example.

Sockets must be fitted as stated in the instructions in the instructions supplied with the charging cord **B**.



42537

Always read the charging cable instructions **carefully** before using it **B**.

Never leave the socket hanging by the cord. Use the hooks **C** to attach it.

If a charging cable malfunctions during the charging process (red warning light on the unit **D**), stop charging immediately. Please refer to cord instructions.



### **Important recommendations for charging your vehicle**

Please read these instructions carefully. Failure to follow these instructions may lead to **a risk of fire, serious injury or electric shocks which could result in death.**

### **Choice of charging cord**

The standard charging leads supplied with the vehicle have been designed specifically for use with this vehicle. It is designed to protect you against the risks of electric shock that can lead to death or fire.

Do not use with the charging leads of previous vehicles as they are not adapted. For safety reasons, the use of a charging cord not recommended by the manufacturer is strictly forbidden. Failure to follow this instruction can lead to risks of fire or electric shock that can prove fatal. For information on a charging cord suited to your vehicle, please consult an authorised dealer.

### **Using the charging lead B**

Please read the instructions that come with the charging cord carefully to learn about precautions you must take when using the product and the technical specifications required when fitting the socket.

## **Installation**

### **Power supply systems**

Only use charging terminals which conform to the IEC 61851-1 standard and connecting points protected by:

- a type A 30 mA residual differential current system specific to the socket used;
- an overcurrent protection device;
- protection against overvoltage relating to lightning in exposed areas (IEC 62305-4).

### **Wall socket**

Have a special wall socket installed by a qualified professional.

### **In the case of domestic charging**

Have a qualified professional check that each socket to which you will connect the charging cord complies with the standards and regulations in force in your country and that it complies with the specifications described previously in the information on “Power supply systems”.

# ELECTRIC VEHICLE: CHARGING (5/10)


## Charging types that conform to European standards

### Alternating current (AC)


If the information is displayed on the vehicle charging flap, follow the instructions below.

Before plugging in a charging lead, check that:

- the colour and one of the letters of the charging terminal inlet socket **1** correspond to the colour and one of the letters at the end **4** of the cable;
- the colour and one of the letters of the inlet socket **3** correspond to the colour and one of the letters on the end **5** of the lead.



49963



53807

Charging type	Alternating current (AC)				
	Charging terminal 1/Charging lead 4			Vehicle 3/Charging lead 5	
Charging types that conform to European standards (for all other cases, please consult an approved dealer).	C	D	E	B	C



# ELECTRIC VEHICLE: CHARGING (6/10)

## Charging types that conform to European standards (continued)

### Direct current (DC)


If the information is displayed on the vehicle charging flap, follow the instructions below.

Before plugging in a charging lead, make sure that the colour and one of the letters of the inlet socket **3** correspond to the colour and one of the letters on the end **5** of the charging lead.



Charging type	Direct current (DC)				
Connection	Vehicle 3/Charging lead 5				
<b>Charging types that conform to European standards</b> (for all other cases, please consult an approved dealer).	K	L	M	N	O

## ELECTRIC VEHICLE: charging (7/10)



### Charging connection 3

The vehicle has a charging connection located at the front of the vehicle.

In the absence of any protection against overvoltage, you are recommended not to charge the vehicle in stormy weather (lightning, etc.).

### Precautions

Avoid charging and parking your vehicle in extreme temperatures (hot or cold).

When the vehicle is parked in temperatures lower than around  $-25^{\circ}\text{C}$ , the battery cannot be charged.

To preserve the service life of your traction battery, avoid parking the vehicle for more than three months with high charge, especially when the weather is very hot.

You must charge the traction battery after driving in very cold weather. Otherwise, charging may take a longer period of time or even become impossible.

### Recommendations


- In extreme heat, favour parking and recharging the vehicle in a shaded/covered location.
- Charging can be performed in the rain or snow.

**Note:** If in a snowy environment, remove snow from the vehicle charging area before plugging in or disconnecting. Snow in the socket may block the insertion of the charging cord plug.

The traction battery charging time depends on the amount of energy remaining, the power delivered by the charging terminal and the temperature conditions (hot or cold). The information is displayed on the instrument panel during charging. Please see the information on “Displays and indicators” in Section 1.

In the event of a problem, we recommend that you replace it with an identical cord. Please see an authorised dealer.

## ELECTRIC VEHICLE: charging (8/10)




### Recharging the traction battery


With the ignition off, lever **6** in gear **P** and opening elements unlocked:

- take the charging cord located in the boot of your vehicle;
- remove it from its storage bag;
- plug in the end of the cord to the power supply (terminal, domestic plug socket, etc.);

The charging cord cannot be plugged in or removed while the opening elements are locked.



- open the charging flap **7**;
- open valve **9**;
- grab the handle **10**;
- plug in the vehicle cord;
- make sure you have clicked the charging cable in properly. The ⚡ warning light on the instrument panel comes on, and the Z.E. **8** blue warning light comes on, then flashes rapidly.



Make sure you fully uncoil the charging cord to limit its heating.




Do not use an extension lead, multiple socket or adapter.

**Fire hazard.**

## ELECTRIC VEHICLE: charging (9/10)

38476



The charging cord is automatically locked with the vehicle. This will make it impossible to unplug the cord from your vehicle.

When charging commences, the hazard warning lights will flash five times. A message on the instrument panel indicates the remaining charging time and the Z.E. 8 warning light flashes slowly.

At the end of a full charge, the Z.E. 8 warning light will remain blue then go out after several minutes.

You do not need to wait until the charge is at reserve levels to recharge your vehicle.

If the Z.E. 8 warning light lights up red, the vehicle cannot start charging; restart the charging procedure.

If the problem persists, change power supply (terminal, etc.) or consult and approved Dealer.



To avoid disturbing the charging monitoring system, do not install any antistatic strip to the vehicle.



~230V/240V




43263

### Label 11

The label **11** on the charging flap reminds you of the instructions for the opening and closing of the flap:

- with the vehicle stationary, the valve and the charging flap can be open;
- when the vehicle is being driven, the valve and the charging flap must be closed.


## ELECTRIC VEHICLE: charging (10/10)





### Precautions to take when removing from the socket

- Press the button **12** on the radio frequency remote control or switch **13** to release the charging cable;
- grab the handle **10**;

After pressing the charging cord release button, you will have around 30 seconds to unplug it before it is locked once again.



- unplug the charging cable from the vehicle. Warning light  goes out on the instrument panel;
- close valve **9**;
- close the charging flap **7**;
- unplug the cord from the power supply;
- store the cord in its storage bag and put away in the boot.




**Note:** immediately after a long charge of the traction battery, the cable may be hot. Please use the handles.

It is imperative to follow the unplugging steps in order.




## KEY, RADIO FREQUENCY REMOTE CONTROL: general information (1/2)



### Radio frequency remote control A

- 1 Locking all the opening elements.
- 2 Unlocking all opening elements and the charging cord.
- 3 Coded key for ignition switch, driver's door and fuel filler cap.

The key must not be used for any function other than those described in the handbook (removing the cap from a bottle, etc.).



### Radio frequency remote control B

- 1 Locking all the opening elements.
- 2 Unlocking all the opening elements.
- 3 Coded key for ignition switch, driver's door and fuel filler cap.
- 4 Locking/unlocking the luggage compartment and, depending on the vehicle, the sliding side doors.

#### Advice

Avoid leaving the remote control in hot, cold or humid areas.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

### RISK OF DEATH OR SERIOUS INJURY.

## KEY, RADIO FREQUENCY REMOTE CONTROL: general information (2/2)

### Radio frequency remote control operating range

This varies according to the surroundings: take care not to lock or unlock the doors by inadvertently pressing the buttons on the remote control.

### Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control) may affect the operation of the remote control.

**Note:** if a door is not opened within approximately 2 seconds of the door being unlocked by remote control, the doors will lock again automatically.

### For replacement, or if you require an additional remote control.

You must only contact an approved Dealer.

- To replace a remote control, the vehicle must be taken to an approved Dealer as both the vehicle and the remote control are needed to initialise the system.
- Depending on the vehicle, you have the option of using up to four remote controls.


### Remote control unit failure

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. These batteries have a service life of approximately two years.

To learn how to change the battery, please refer to the information on the “Key, radio frequency remote control: Batteries” in Section 5.

## KEY, RADIO FREQUENCY REMOTE CONTROL: Use (1/2)

**A**




26519

The doors are locked and unlocked using the remote control unit.

It is powered by a battery which must be replaced (refer to the information on the “Key, radio frequency remote control: batteries” in Section 5).

**B**



102A

### Locking the doors

#### Remote control **A** or **B**

Press locking button **1**.

The hazard warning lights and side indicator lights **flash twice** to indicate that the doors have locked.

If a door or the tailgate is open or not properly shut, the doors and tailgate lock then quickly unlock and the hazard warning lights and side indicator lights do not flash.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

# RADIO FREQUENCY REMOTE CONTROL, KEY: use (2/2)

(A)



26519

## Unlocking the doors

### Remote control A or B


Press unlocking button 2.

Pressing the button briefly unlocks all the doors.

A short press on button 3 locks/unlocks the tailgate and, depending on the vehicle, the sliding side doors.

The hazard warning lights and side indicator lights **flash once** to indicate that the doors have unlocked.

(B)




102A

**Note:** unlocking the opening elements will unlock the vehicle charging cord.

The key must not be used for any function other than those described in the handbook (removing the cap from a bottle, etc.).

# DEADLOCKING




26519

If fitted to the vehicle, this allows the doors to be locked and prevents them from being opened with the interior handles (for example, by breaking the window and then trying to open the doors from the inside).



Never use deadlocking if someone is still inside the vehicle.



102A

## To activate deadlocking

Press button **1** twice in quick succession.

The side indicator lights and hazard warning lights **flash five times** to indicate that the doors have locked.

## To deactivate deadlocking

Unlock the vehicle using button **2**.


The hazard warning lights and side indicator lights **flash once** to indicate that the doors have unlocked.

## Special feature

For vehicles equipped with deadlocking, when the vehicle is charging, every time one of the doors is unlocked, opened or closed, check that charging is still in progress.

If not, the charging process needs to be restarted (connecting the cord, programming, etc.). Refer to the paragraph “Electric vehicle: charging” in section 1.

## OPENING AND CLOSING THE DOORS (1/4)



### Opening from the outside

Unlock the door and pull handle **1**. For information on unlocking the doors, refer to the information on the “Key, radio frequency remote control: use” in Section 1.


### Opening from the inside

Pull handle **2**.

### Closing from the inside


Pull handle **3**.


**Note:** do not use the handle **2** to close the door.



### Lights-on reminder buzzer

A warning beep sounds when the driver's door is opened to warn you that the lights are still on (to prevent discharge of the 12 volt battery).

 This warning indicates that a door is open or not properly closed.




### Child safety

(depending on vehicle)

At the rear, to prevent the side door from being opened from the inside, move lever **4** using the end of the vehicle key.

From the inside, check that the door is correctly locked.

## OPENING AND CLOSING THE DOORS (2/4)



### Sliding side door

#### Opening from the outside


Unlock the door and pull handle **5**, then slide the door towards the rear of the vehicle until it locks in position. For information on unlocking the doors, refer to Section 1 “Key, radio frequency remote control: use”.

#### Opening from the inside

Pull handle **7** and use handle **6** to slide the door towards the rear of the vehicle until it locks in position.

#### Closing from the inside

Pull handle **5** towards the front of the vehicle until the door is completely closed.



As a safety measure, the sliding side door located on the fuel filler flap side locks when the flap is opened. For more information, refer to the information on the “Central door locking/unlocking” in Section 1.




### Recommendations concerning the sliding side door

The following precautions must be taken when opening and closing the doors or any other opening element:

- Check that the door will not come into contact with any person, animal or object.
- Only use the handles on the inside and outside of the door to operate it.
- Take care when opening and closing the door.
- Take particular care when the vehicle is parked on a slope: open the door with care until it is fully open and latches into its locking position.
- Before moving off, always ensure that the sliding door is properly closed.
- Do not use the lower support as a step.

## OPENING AND CLOSING THE DOORS (3/4)




### Rear hinged doors

#### Opening from the outside

Unlock the door and pull handle **8**. For information on unlocking the doors, refer to Section 1 “Key, radio frequency remote control: use”.



Do not leave the hinged rear doors open in case of strong winds. Risk of injury.



#### Opening the doors to the maximum position

For each door, pull handle **9** to release the door check strap. Open the door as far as possible.

#### Closing manually from the outside

First close the small door and then close the large door.


Position each door so that it is almost closed and then slam shut.



If the vehicle is parked on the hard shoulder with the tailgate open, the rear lights may be obscured. You should make other road-users aware of your vehicle by using a warning triangle or other equipment specified by the road traffic regulations of the country concerned.



## OPENING AND CLOSING THE DOORS (4/4)



### Rear hinged doors (continued)

#### Opening from the inside (depending on vehicle)

Pull handle **11** and open the door. Pull lever **10** to open the small door.

#### Closing from the inside

First close the small door and then close the large door.

Position each door so that it is almost closed and then slam shut.



#### Driver's responsibility when parking or stopping the vehicle


Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## CENTRAL DOOR LOCKING, UNLOCKING (1/2)



### Control for locking and unlocking from the inside

This enables all the doors to be locked simultaneously.

Lock or unlock the doors by pressing switch **1**.

If a door or the tailgate is open or not closed properly, the doors and tailgate lock/unlock quickly.



Never leave your vehicle with the key inside the vehicle.

### Locking the opening elements without the remote control

With the engine and ignition off, the sliding side doors closed and a front door open, press switch **1** for more than five seconds.

Make sure you have your key with you before you leave your vehicle.

When the door is closed, all the doors and tailgate will be locked.

Unlocking from outside the vehicle will only be possible with the key for the driver's door.

### Doors and tailgate status indicator light

**With the ignition on**, the warning light integrated in switch **1** informs you of the locking status of the opening elements:

- indicator light on, the doors and tailgate are locked;
- indicator light off, at least one door is unlocked.


When you lock the doors, the indicator light remains lit and then goes out.

Unlocking the opening elements by pressing the switch **1** releases the vehicle charging cord.



If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

## CENTRAL DOOR LOCKING, UNLOCKING (2/2)



### Manual control

#### Using the key

Lock or unlock the driver's door by inserting the key **3** fully into lock **2**, and turning the key.

For more information on the remote controls, refer to the information on the "Key, radio frequency remote control: use" in Section 1.

#### Locking the doors manually

Turn screw **4** with the door open (using the end of the key) and close the door. This means that the doors are then locked from the outside.




The doors may then only be opened from inside the vehicle or with the key for the front doors.

### Sliding side door (fuel filler cap side)

To prevent the door striking the fuel filler nozzle, a mechanical system locks it when the fuel filler flap is open.

When the fuel tank has been filled, replace the cap in its housing and close the flap. The door can now be used.

# AUTOMATIC LOCKING WHEN DRIVING (RAID)



**You must first decide if you want to activate this function.**

## To activate

**With the engine running**, press and hold button **1** for approximately 5 seconds, until you hear a beep. The indicator light built into the control comes on when the doors are locked.

## To deactivate

**With the engine running**, press and hold button **1** for approximately 5 seconds, until you hear a beep.

## Operating principle

When the engine is started, the system automatically locks the doors when the vehicle reaches a speed of approximately 4 mph (7 km/h).

## Operating faults

If you notice an operating fault (automatic locking impossible), first check that all doors are correctly locked. If they are correctly locked and the fault is still present, contact an approved Dealer.

Also make sure that locking has not been inadvertently deactivated.


If necessary, refer to the activation procedure.



If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

# FRONT HEADRESTS (1/3)

38152



## Headrest A

### To raise the headrest

Pull it upwards to the required height.

### To lower the headrest

Pull the tab **2** forwards, gently lift the headrest to unlock it and guide it down to the required height.

### To remove the headrest

Raise it to its highest position. Press button **1** and lift the headrest to release it.

### To refit the headrest

First, check that the headrest rods are clean and correctly aligned.

Pull the tab **2** forwards.

Insert the headrest rods in the holes, with the notches facing forwards (tilt the seat backwards if necessary).

Guide the headrest down to the desired height.

26342




The headrest is an important safety component: ensure that it is in place and in the correct position.

The distance between your head and the headrest should be as small as possible. The top of your head should be in line with the top of the headrest.

## FRONT HEADRESTS (2/3)

27323



### Headrest B

#### To raise the headrest

Pull it upwards to the required height.

#### To lower the headrest

Press button **3** and guide the headrest down to the desired height.

#### To remove the headrest

Raise it to its highest position. Press button **4** and lift the headrest to release it.


**Note:** when the headrest is removed, take care not to change the positions of the rods.

#### To refit the headrest

If the setting of the rods has been altered, pull them fully upwards. Take care to ensure they are clean and correctly aligned and, if there are any problems, check that the notches are facing forwards.

Insert the headrest rods into the holes (tilt the seatback backwards if necessary).

Lower the headrest until it locks, press button **3** and lower the headrest as far as possible.



26342



The headrest is an important safety component: ensure that it is in place and in the correct position.

The distance between your head and the headrest should be as small as possible. The top of your head should be in line with the top of the headrest.

## FRONT HEADRESTS (3/3)



### Headrest C

#### To raise the headrest

Pull it upwards to the required height.

#### To lower the headrest

Press tab **5** and guide the headrest down to the desired height.

#### To remove the headrest


Raise it to its highest position. Press tabs **5** and **6** then lift the headrest to release it.

**Note:** when the headrest is removed, take care not to change the positions of the rods.

#### To refit the headrest

Press tab **5**.


Insert the headrest rods in the holes with the notches facing forward, and guide the headrest down to the required height.



The headrest is an important safety component: ensure that it is in place and in the correct position.

The distance between your head and the headrest should be as small as possible. The top of your head should be in line with the top of the headrest.

## FRONT SEATS (1/2)



### To move forwards or backwards

Depending on the seat, lift bar **1** or handle **4** to release it. Release the handle at the desired position and make sure that it is locked.

### Adjusting the height of the driver's seat

Move lever **3** as many times as necessary:

- upwards to raise the seat,
- downwards to lower the seat.



### To tilt the seatback

Depending on the seat, lower or lift lever **2** and tilt the seatback until it reaches the required position.



For safety reasons, carry out any adjustments when the vehicle is not being driven.



After making adjustments, make sure that the seatbacks are correctly locked in place.



To avoid all risk of injury, ensure that nobody is in the proximity of the moving parts. When moving the seat, make sure that nothing interferes with the moving parts and their locking.



For safety reasons, carry out any adjustments when the vehicle is not being driven.


We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced.

Make sure that the seatbacks are correctly locked in place.

Nothing should be placed on the floor (area in front of driver) as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.




## FRONT SEATS(2/2)



### Heated seats

Ignition switch to a position other than the “Stop and steering lock” position St, press switch **5**, an indicator light will come on.



### Operating faults


(depending on vehicle)

If the sliding side door does not work, lower handle **6**, hold it while the seat-back tilts and slide the seat forwards.

To place the seat into the comfort position, slide it rearwards.

Adjust the seat and make sure that it is correctly locked.

## SWIVELLING PARTITION



### To rotate the partition

- Unlock the seat base by moving handle **1** downwards;
- lift the front passenger seat base vertically (arrow);
- lower headrest **2** to its lowest setting;
- unlock the seatback by moving handle **1** downwards again and position the seatback horizontally. To make the manoeuvre easier, rotate the headrest **2**;



- unlock the swivelling section by lifting catch **3**;
- reposition the seat base, proceeding in reverse order.

When moving the swivelling partition, ensure the seat belt is not damaged. Hold it aside when you rotate the partition.



- Pivot the moving section 90 degrees, lock it at point **5** and lower catch **3**.

**Note:** before refitting the swivelling section in its original position, check that locking point **4** is clean.

Maximum weight on the seat in table position is 80 kg. The weight must be evenly distributed.



The swivelling section must always be locked when the vehicle is driven. Risk of injury.

## SEAT BELTS (1/4)

Always wear your seat belt when travelling in your vehicle. You must also comply with the legislation of the particular country you are in.

Make sure that the rear bench seat is locked in position correctly so that the rear seat belts will operate efficiently. Refer to "Rear bench seat: functions" in Section 3.



Seat belts which are incorrectly adjusted or twisted may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult.

Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

**Before starting, first adjust your driving position, then ask all occupants to adjust their seat belts to ensure optimum protection.**

### Adjusting your driving position

- **Sit well back in your seat** (having first removed your coat or jacket). This is essential to ensure your back is positioned correctly;
- **adjust the distance between the seat and the pedals.** Your seat should be as far back as possible while still allowing you to fully depress the pedals. The seatback should be adjusted so that your arms are slightly bent when you hold the steering wheel;
- **adjust the position of your headrest.** For maximum safety, your head must be as close as possible to the headrest;
- **adjust the height of the seat.** This adjustment allows you to select the seat position which offers you the best possible view;
- **adjust the position of the steering wheel.**



### Adjusting the seat belts

Sit with your back firmly against the seatback.

The shoulder strap **1** should be as close as possible to the base of the neck but not on it.

The lap belt **2** should be worn flat over the thighs and against the pelvis.

The seat belt must be worn as close to the body as possible. e.g. avoid wearing heavy clothing, keeping bulky objects under the belts, etc.

## SEAT BELTS (2/4)

13622



### Locking

Unwind the belt **slowly and smoothly** and ensure that buckle **3** locks into catch **5** (check that it is locked by pulling on buckle **3**).

If the belt jams, allow it to return slightly before attempting to unwind it again.

If your seat belt is completely jammed, pull slowly, but firmly so that just over 3 cm unwinds. Allow it to return slightly before attempting to unwind it again.

If there is still a problem, contact an approved dealer.

### Unfastening


Press button **4** and the seat belt will be rewound by the inertia reel. Guide the belt.



### Driver's seat belt reminder and, depending on the vehicle, front passenger seat belt reminder

This appears on the display **6** when the ignition is switched on if the driver's and/or front passenger's seat belt(s) (if the passenger seat is occupied) are not fastened.

Depending on the vehicle, if the seat is occupied and one of these seat belts is not fastened or becomes unfastened while the vehicle is moving at a speed over approximately 12 mph (20 km/h),


the  warning light flashes and a beep sounds for approximately 120 seconds.

**Note:** an object placed on the passenger seat may activate the warning light in some cases, depending on the vehicle.

38442



## SEAT BELTS (3/4)




### Adjusting the front seat belt height

Press button **7** to adjust the seat belt height so that shoulder strap **1** is worn as shown previously:

- to lower the seat belt, press button **7** and lower the seat belt at the same time;
- to raise the seat belt, press button **7** and lift the seat belt to the required position.

Make sure that the seat belt is locked in position correctly after you have adjusted it.



### Rear centre belt

Unwind the belt slowly and ensure that the buckle **8** locks into catch **11**.

Make sure that the rear bench seat is securely locked in position so that the rear seat belts will operate efficiently. Refer to the information on the “Rear bench seat: functions” in Section 3.

### Rear side seat belts

Unwind the belt **slowly and smoothly** and ensure that buckle **9** locks into catch **10** (check that it is locked by pulling on buckle **9**).

The belts are adjusted in the same way as the front seat belts.

The **five-seater** version complies with the local regulations in the country where the vehicle is sold.



Check that the rear seat belts are positioned and operating correctly each time the rear seats are moved.

## SEAT BELTS (4/4)



- No modification may be made to the component parts of the originally fitted restraint system: belts, seats and their mountings. For special operations (e.g. fitting child seats), contact an authorised dealer.
- Do not use devices which allow any slack in the belts (e.g. clothes pegs, clips, etc.): a seat belt which is worn too loosely may cause injury in the event of an accident.
- Never wear the shoulder strap under your arm or behind your back.
- Never use the same belt for more than one person and never hold a baby or child on your lap with your seat belt around them.
- The belt should never be twisted.
- Following an accident, have the seat belts checked and replaced if necessary. Always replace your seat belts as soon as they show any signs of wear.
- Make sure that the buckle is inserted into the appropriate catch.
- When the rear bench seat is being put back, make sure that the seat belts and buckles are correctly positioned so that they can be used properly.
- Ensure that no objects are placed in the area around the seat belt catch as they could prevent it from being properly secured.
- Make sure the seat belt catch is properly positioned (it should not be hidden away, crushed or flattened by people or objects).

## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (1/5)


Depending on the vehicle, they will consist of:

- **seat belt pretensioners;**
- **front airbags 1 for driver and front passenger.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can trigger:

- seat belt locking<sup>2</sup>;
- the seat belt pretensioner (which engages to correct seat belt slack);
- the front air bag.



### Pretensioners

The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

With the ignition on, following a significant frontal impact and depending on the severity of the impact, the system may trigger the seat belt pretensioner which instantly retracts the seat belt.



– Have the entire restraint system checked following an accident.

– No operation whatsoever is permitted on any part of the system (pretensioners, air bags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.

– To avoid incorrect triggering of the system which may cause injury, only qualified personnel from an approved dealer may work on the pretensioner and air bag system.

– The electric trigger system may only be tested by a specially trained technician using special equipment.

– When the vehicle is scrapped, contact an approved dealer for disposal of the pretensioner and air bag gas generators.


# METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (2/5)

## Driver and passenger front airbags

They are fitted to the front seats on the driver's side and, depending on the vehicle, on the passenger's side as well.

Depending on the vehicle, the presence of this equipment is indicated by the word "airbag" on the steering wheel and dashboard (airbag zone **A**) and a symbol on the lower section of the windscreen.

Each airbag system consists of:

- an air bag and gas generator fitted on the steering wheel for the driver and in the dashboard for the front passenger;
- an electronic unit for system monitoring which controls the gas generator electrical trigger system;
- a single indicator light  on the instrument panel;
- remote sensors.


## Operation

This system is only operational when the ignition is switched on.

In a severe **frontal** impact, the air bags inflate rapidly, cushioning the impact of the driver's head and chest against the steering wheel and of the front passenger against the dashboard. The air bags then deflate immediately so that the passengers are not in any way hindered from leaving the vehicle.

## Load limiter


Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.



The air bag system uses pyrotechnic principles. This explains why, when the air bag inflates, it will generate heat, produce smoke (this does not mean that a fire is about to start) and make a noise upon detonation. In a situation where an air bag is required, it will inflate immediately and this may cause some minor, superficial grazing to the skin or other problems.




## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (3/5)




The following cases trigger the pretensioners or airbags.

**In a frontal impact** against a rigid (non-deformable) surface at an impact speed equal to or greater than **16 mph (25 km/h)**.



**In a frontal impact** with another vehicle of an equivalent or higher category, with an impact area equal to or greater than 40%, where the speed of both vehicles is equal to or greater than **25 mph (40 km/h)**.



**In a side impact** with another vehicle of an equivalent or higher category, at an impact speed equal to or greater than **31 mph (50 km/h)**.

## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (4/5)



44449




In the following examples, the pretensioners or the airbags could operate:

- impact under vehicle such as pavement;
- potholes;
- drop or hard landing;
- stones;
- ...




44450



In the following examples, there is a risk that pretensioners or airbags may not be triggered:

- rear impact, however severe;
- the vehicle overturning;
- ...



44451



- side impact to the front or rear of the vehicle;
- frontal impact, under the tail of a lorry;
- frontal impact against an obstacle with a sharp angle;
- ...

## METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS (5/5)

All of the warnings below are given so that the air bag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when the air bag inflates.



### Warnings concerning the driver's air bag

- Do not modify the steering wheel or the steering wheel boss.
- Do not cover the steering wheel boss under any circumstances.
- Do not attach any objects (badge, logo, clock, telephone support, etc.) to the steering wheel boss.
- The steering wheel must not be removed (except by qualified personnel from our Network).
- Do not sit too close to the steering wheel when driving: sit with your arms slightly bent (see Section 1 “Adjusting your driving position”). This will allow sufficient space for the airbag to deploy correctly and be fully effective.

### Warnings concerning the passenger air bag

- Do not attach or glue any objects (badge, logo, clock, telephone cradle, etc.) to the dashboard in the airbag zone.
- Do not place anything between the dashboard and the passenger (animal, umbrella, walking stick, parcels, etc.).
- The passenger must not put his or her feet on the dashboard or seat as there is a risk that serious injuries may be sustained. As a general rule, keep all body parts (knees, hands, head, etc.) away from the dashboard.
- The devices in addition to the front passenger seat belt should be reactivated as soon as a child seat is removed, to ensure the protection of the passenger in the event of an impact.

**A REAR-FACING CHILD SEAT MUST NOT BE FITTED TO THE FRONT PASSENGER SEAT UNLESS THE ADDITIONAL RESTRAINT SYSTEMS, I.E. THE PASSENGER AIR BAG, ARE DEACTIVATED.**

(Refer to the information on “Child safety: front passenger airbag deactivation/activation” Section 1).

## SIDE PROTECTION DEVICES

### Side air bags

(depending on vehicle)

This air bag may be fitted to each of the front seats and is activated at the sides of the seats (door side) to protect the occupants in the event of a severe side impact.

### Curtain air bags

(depending on vehicle)

These airbags may be fitted along the top of each side of the vehicle and are triggered along the front and rear side door windows to protect the passengers in the event of a severe side impact.

Depending on the vehicle, a marking on the windscreen informs you of the presence of additional means of restraint (airbags, pretensioners, etc.) in the passenger compartment.



#### Warnings concerning the side air bag

- **Fitting seat covers:** seats equipped with an airbag require covers specifically designed for your vehicle. Contact an authorised dealer to find out if these covers are available. The use of any covers other than those designed for your vehicle (including those designed for another vehicle) may affect the operation of the airbags and reduce your protection.
- Do not place any accessories, objects or even pets between the seatback, the door and the internal fittings. Do not cover the seatback with any items such as clothes or accessories. This may prevent the air bag from operating correctly or cause injury when the air bag is deployed.
- No work or modification whatsoever may be carried out on the seat or internal fittings, except by qualified personnel from an approved Dealer.
- These airbags operate through slits in the front seatbacks (door side): Never place any objects here.

## ADDITIONAL METHODS OF RESTRAINT

All of the warnings below are given so that the air bag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when the air bag inflates.



The air bag is designed to complement the action of the seat belt. Both the air bags and seat belts are integral parts of the same protection system. It is therefore essential to wear seat belts at all times. If seat belts are not worn, the occupants are exposed to the risk of serious injury in the event of an accident. It may also increase the risk of minor superficial injuries occurring when the air bag is deployed, although such minor injuries are always possible with air bags.

If the vehicle should overturn or suffer a rear impact, however severe, the pretensioners and air bags are not always triggered. Impacts to the underside of the vehicle, eg. from pavements, potholes or stones, can all trigger these systems.

- No work or modification **whatsoever** may be carried out on any part of the air bag system (air bags, pretensioners, computer, wiring harness, etc.), except by qualified personnel from an approved Dealer.
- To ensure that the system is in good working order and to avoid accidental triggering of the system which may cause injury, only qualified Network personnel may work on the air bag system.
- As a safety precaution, have the airbag system checked if your vehicle has been involved in an accident, or is stolen or broken into.
- When selling or lending the vehicle, inform the user of these points and hand over this handbook with the vehicle.
- When scrapping your vehicle, contact your approved Dealer for disposal of the gas generator(s).



### Operating faults

This warning light **1** will light up on the instrument panel when the ignition is switched on and then go out after a few seconds.

If it does not come on when the ignition is switched on, or if it comes on when the engine is running, there is a fault with the system (airbags, pretensioners, etc.) in the front and/or rear seats.

Contact your approved dealer as soon as possible. Your protection will be reduced until this fault is rectified.

## CHILD SAFETY: General information (1/2)

### Carrying children

Please ensure that you comply with the legislation of your country.

Children, and adults, must be correctly seated and strapped in for all journeys. The children being carried in your vehicle are your responsibility.

A child is not a miniature adult. Children are at risk of specific injuries as their muscles and bones have not yet finished growing. The seat belt alone would not provide suitable protection. Use an approved child seat and ensure you use it correctly.



To prevent the doors being opened, use the “Child safety” device (refer to the information on “Opening and closing the doors” in Section 1).



A collision at 30 mph (50 km/h) is the same as falling a distance of 10 metres.

Transporting a child without a restraint is the equivalent of allowing him or her to play on a fourth-floor balcony without railings.

Never travel with a child held in your arms. In the event of an accident, you will not be able to keep hold of the child, even if you yourself are wearing a seat belt.

If your vehicle has been involved in a road accident, replace the child seat and have the seat belts and ISOFIX anchorage points checked.



### **Driver's responsibility when parking or stopping the vehicle**

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## CHILD SAFETY: General information (2/2)

### Using a child seat

The level of protection offered by the child seat depends on its ability to restrain your child and on its installation. Incorrect installation compromises the protection it offers the child in the event of harsh braking or an impact.

Before purchasing a child seat, check that it complies with the regulations for the country you are in and that it can be fitted in your vehicle. Consult an approved dealer to find out which seats are recommended for your vehicle.

Before fitting a child seat, read the manual and respect its instructions. If you experience any difficulties during installation, contact the manufacturer of the equipment. Keep the instructions with the seat.

Set a good example by always fastening your seat belt and teaching your child:

- to strap themselves in correctly.
- to always get in and out of the car at the kerb, away from busy traffic.

Do not use a second-hand child seat or one without an instruction manual.

Check that there are no objects in the vicinity of the child seat which could impede its operation.



Never leave a child unattended in the vehicle.

Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. Avoid wearing bulky clothing which could cause the belts to slacken.

Never let your child put their head or arms out of the window.

Check that the child is in the correct position for the entire journey, especially if asleep.

## CHILD SAFETY: choosing a child seat



31235

### Rear-facing child seats

A baby's head is, proportionally, heavier than that of an adult and its neck is very fragile. Transport the child in this position for as long as possible (until the age of 2 at the very least). It supports both the head and the neck.

Choose a bucket type seat for best side protection and change it as soon as the child's head is higher than the shell.



38824

### Forward-facing child seats

Up to 18 kg or 4 years, the child may travel on a forward-facing seat.

Choose your seat according to the child's size: their head and abdomen are the areas which must be most protected. A forward-facing child seat which is firmly attached to the vehicle will reduce the risk of impact to the head. Ensure your child travels in a forward-facing seat with a harness for as long as their size permits.

Choose a bucket type seat for optimum side protection.



31234

### Booster cushions

From 15 kg or 4 years, the child can travel using a booster seat, which will enable the seat belt to be adapted to suit his/her size and shape. The booster seat cushion must be fitted with guides to position the seat belt on the child's thighs rather than the stomach. It is recommended that you use a seat-back fitted with a belt strap guide which can be adjusted in terms of height to position the seat belt in the centre of the shoulder. It must never rest on the neck or on the arm.

Choose a bucket type seat for optimum side protection.



## CHILD SAFETY: choosing a child seat mounting (1/3)

There are two ways of attaching child seats: via the seat belt or using the ISOFIX system.

### Attachment via the seat belt

The seat belt must be adjusted to ensure that it is effective in the event of harsh braking or an impact.

Ensure that the strap paths indicated by the child seat manufacturer are respected.

Always check that the seat belt is correctly fastened by pulling it up, then pulling it out fully whilst pressing on the child seat.

Check that the seat is correctly held by moving it from side to side and back to front: the seat should remain firmly fixed.

Check that the child seat has not been installed at an angle and that it is not resting against a window.



No modifications may be made to the component parts of the restraint system (belts, ISOFIX and seats and their mountings) originally fitted.



The seat belt must never be twisted or the tension relieved. Never pass the shoulder strap under the arm or behind the back. Check that the seat belt has not been damaged by sharp edges. If the seat belt does not operate normally, it will not protect the child. Consult an approved Dealer. Do not use this seat until the seat belt has been repaired.



Do not use the child seat if it may unfasten the seat belt restraining it: the base of the seat must not rest on the buckle and/or catch of the seat belt.

### Attachment with the ISOFIX system

Authorised ISOFIX child seats are approved in accordance with regulation ECE-R44 in one of the three following scenarios:

- ISOFIX universal 3 point forward-facing seat;
- ISOFIX semi-universal 2 point seat;
- specific.

For the latter two, check that your child seat can be installed by consulting the list of compatible vehicles.


Attach the child seat with the ISOFIX locks, if these are provided. The ISOFIX system allows quick, easy, safe fitting.

The ISOFIX system consists of 2 rings and, in some cases, a third ring.




Before using an ISOFIX child seat that you purchased for another vehicle, check that its installation is authorised. Consult the list of vehicles which can be fitted with the seat with the equipment manufacturer.

## CHILD SAFETY: choosing a child seat mounting (2/3)



The two rings **1** are located between the seatback and the seat base, behind the zip fasteners, and are identified by a marking.


The third ring is used to attach the upper strap on some child seats.



Depending on the vehicle, pass the strap between the wheel arch liner **3** and the underside of the upper partition **4**.

From the luggage compartment, attach the strap hook to ring **2** on the corresponding side. Check that the bench seatback is correctly locked.

Pull the belt so that the back of the child seat comes into contact with the back of the vehicle seat.



Luggage compartment anchorages (rings) **2** cannot be used if they are already being used to secure two of the three following components: luggage net, load in the luggage compartment or child seat.

## CHILD SAFETY: choosing a child seat mounting (3/3)



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these anchorage points.

Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.



The child seat strap **must** be attached to the corresponding ring.

Do not use any other mounting point.

## CHILD SAFETY: fitting a child seat: general information (1/2)

Some seats are not suitable for fitting child seats. The diagrams on the following pages show you how to attach a child seat.

The types of child seats indicated may not be available. Before using a different child seat, check with the manufacturer that it can be fitted.



Fit the child seat in a rear seat wherever possible.

To install an ISOFIX seat in this seat, unbuckle the seat belt by hand before engaging the bolts.



Fitting a seat ISOFIX in the rear-left seat means the middle seat cannot be used. The central seat belt will no longer be either accessible or useable.

### In the front seat

The laws concerning children travelling in the front passenger seat differ in every country. Consult the legislation in force and follow the indications on the diagrams on the following pages.

Before fitting a child seat in this seat (if authorised):

- lower the seat belt as far as possible;
- move the seat as far back as possible;
- gently tilt the seatback away from vertical (approximately 25°);
- on equipped vehicles, raise the seat base as far as possible.

In all cases, for vehicles fitted with adjustable headrests, lift the headrest on the seat as high as possible so that it does not interfere with the child seat (refer to the information on “Front headrest” in section 1).

After installing the child seat, when this is possible, you can move the vehicle seat forward if necessary (so as to leave enough space in the rear seats for passengers or other child seats). For a rear-facing child seat, do not let it touch the dashboard or move it to the furthest forward position.

Do not change these settings after the child seat is installed.



### **RISK OF DEATH OR SERIOUS INJURY:**

before installing a child seat on this seat, check that the airbag has been deactivated (refer to “Child safety: front passenger airbag deactivation/activation” in Section 1).

## CHILD SAFETY: fitting a child seat: general information (2/2)

### In the rear seat

A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.

For the safety of the child in the forward-facing seat, do not move the seat in front back past the middle of the runner, do not tilt the seatback too far (maximum of 25°) and raise the seat as much as possible.

Check that the forward-facing child seat is resting against the back of the vehicle seat and that the headrest of the vehicle is not obstructing its use.



A child seat with a floor support must never be installed on the rear centre seat.

**RISK OF DEATH OR SERIOUS INJURY.**

### Child's convertible headrest

If fitted to the vehicle, the child headrest and booster cushion can only be installed on the rear side seats.

For fitting and use, refer to the equipment instructions.



When fitting a child seat (Group 2 or 3 booster seat), check that the seat belts operate (wind) correctly: refer to Section 1 "Rear seat belts". If necessary, adjust the position of the vehicle seat.




Ensure that the child seat or the child's feet do not prevent the front seat from locking correctly. Refer to the information on the "Front seat" in Section 1 or "Rear seat operation" in Section 3.


## CHILD SEATS: attachment by seat belt (1/4)

### Van version with two front seats



56804

 Seat not suitable for fitting child seats.

 Check the status of the airbag before allowing a passenger to use the

The van version with **two front seats** complies with European regulations.

seat.


**X** = Seat not suitable for fitting child seats of this type.


Type of seat group (weight of the child)	Seats suitable for fitting a child seat Front passenger seat	
	WITH PASSENGER AIRBAG	WITHOUT PASSENGER AIRBAG
<b>Group 0, 0+</b> (weight below 13 kg)	X	X
<b>Group I</b> (weight from 9 kg to 18 kg)	X	X
<b>Groups II and III</b> (weight from 15 kg to 36 kg)	X	X

## CHILD SEATS: attachment by seat belt (2/4)


### Five-seater version



 Seat not suitable for fitting child seats.

 Check the status of the air bag before fitting a child seat or allowing a passenger to use the seat.

#### Child seat attached using the belt

 Seat which allows a child seat with “Universal” approval to be attached by a seat belt.



Using a child safety system which is not approved for this vehicle will not properly protect the baby or child. They risk serious or even fatal injury.

The **five-seater** version complies with the local regulations in the country where the vehicle is sold.



**RISK OF DEATH OR SERIOUS INJURY:** before installing a rear-facing child seat in the front passenger seat, make sure that the airbag has been deactivated (see the information on “Child safety: front passenger airbag deactivation/activation” in Section 1).

## CHILD SEATS: attachment by seat belt (3/4)

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

Five-seater version Type of child seat	Weight of the child	Front passenger seat	Rear side seats	Rear centre seat
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	X	U (3)	U (3)
<b>Shell seat/rear-facing seat</b> Group 0, 0+ and 1	< 13 kg and 9 to 18 kg	U (1) (2)	U (4)	U (4)
<b>Forward-facing seat</b> Group 1	9 to 18 kg	X	U (5)	U (5)
<b>Booster seat</b> Group 2 and 3	15 to 25 kg and 22 to 36 kg	X	U (5)	U (5)



**(1) RISK OF DEATH OR SERIOUS INJURY:** before installing a rear-facing child seat in the front passenger seat, make sure the air bag has been deactivated (refer to the information on “Child safety: front passenger air bag deactivation/activation” in Section 1).



## **CHILD SEATS: attachment by seat belt (4/4)**

**X** = Seat not suitable for fitting child seats of this type.

**U** = Seat allowing a child seat with “Universal” approval to be attached by the seat belt; check that it can be fitted.

- (2) Only a rear-facing child seat can be fitted in this seat: position the vehicle seat as far back and raise it as much as possible, and tilt the seatback slightly (approximately 25°).
- (3) A carrycot is fitted crosswise and occupies at least two seats (the child’s feet are placed nearest the door).
- (4) In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.
- (5) Forward-facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. Adjust the headrest, or remove it if necessary. In addition, do not push the seat in front of the child further than halfway along its runners, or incline the seatback more than 25°.

## CHILD SEATS: attachment using the ISOFIX SYSTEM (1/3)

The table below summarises the information already shown on the diagram on the next page, to ensure the regulations in force are respected.

Five-seater version Type of child seat	Weight of the child	Seat size ISOFIX [Height]	Front passenger seat	Rear side seats	Rear centre seat
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	F, G [L1, L2]	X	IL (1)	X
<b>Rear-facing shell seat</b> Group 0 or 0+	< 13 kg	E [R1]	X	IL (2)	X
<b>Forward facing seat/shell seat</b> Group 0+ and 1	< to 13 kg and 9 to 18 kg	C, D [R3, R2]	X	IL (2)	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	A, B ,B1 [F3, F2, F2X]	X	IUF - IL (3)	X
<b>Booster seat</b> Group 2 and 3	15 to 25 kg and 22 to 36 kg		X	IUF - IL (3)	X
<b>I-Size seats</b>			X	X	X

## CHILD SEATS: attachment using the ISOFIX SYSTEM (2/3)

**X** = Seat not suitable for fitting child seats of this type.

**IUF/IL** = On equipped vehicles, seat which allows a child seat with "Universal/Semi-universal or vehicle-specific" approval to be fitted using the ISOFIX system; check that it can be fitted.


- (1) A carrycot is fitted crosswise and occupies at least two seats (the child's feet are placed nearest the door).
- (2) If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.
- (3) In all situations, remove the headrest from the rear seat on which the child seat is fitted. This must be done before fitting the child seat. Please refer to the information on the "Rear headrests" in Section 3. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1 [F3, F2, F2X]: for forward-facing seats in group 1 (9 to 18 kg);
- C and D [R3, R2]: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- E [R1]: rear-facing shell seats in group 0 (less than 10 kg) or 0+ (less than 13 kg);
- F and G [L1, L2]: for carrycots in group 0 (under 10 kg).

# CHILD SEATS: attachment using the ISOFIX SYSTEM (3/3)

## Five-seater version



57182



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



Seat not suitable for fitting child seats.

### Child seats attached using ISOFIX mounting



Seat which allows an ISOFIX child seat to be fitted.




The rear seats are fitted with an anchorage point which allows a forward-facing ISOFIX child seat with universal approval to be attached. The anchorage points are located in the luggage compartment and are visible.

The size of the ISOFIX child seat is indicated by a letter:

- A, B and B1 [F3, F2, F2X]: for forward-facing seats in group 1 (9 to 18 kg);
- C [R3]: for rear-facing seats in group 1 (9 to 18 kg);
- D and E [R2, R1]: shell seats or rear-facing seats in group 0 or 0+ (less than 13 kg);
- F and G [L1, L2]: for carrycots in group 0 (under 10 kg).

The **five-seater** version complies with the local regulations in the country where the vehicle is sold.


## CHILD SAFETY: deactivating, activating the front passenger airbag (1/3)



### Deactivating the front passenger airbag

Before installing a child seat on the front passenger seat:

- check that the child seat can be installed on this seat;
- it is essential **to deactivate** the airbag for a rear-facing child seat.



**To deactivate the airbag: with the vehicle stationary and the ignition off,** push and turn the lock **1** to the OFF position.

With the ignition on, you **must** check that warning light **2** is lit on the central display and, depending on the vehicle, that the message "PASSENGER AIRBAG OFF" is displayed.

**Note:** on vehicles fitted with this, the side airbag is also deactivated.

**This light remains permanently lit to let you know that you can fit a child seat.**



The passenger airbag must only be activated or deactivated **while the vehicle is stationary** with the ignition off.

If it is interfered with when the vehicle is being driven, indicator lights



and will come on.

Switch the ignition off then on again to reset the airbag in accordance with the lock position.

## CHILD SAFETY: deactivating, activating the front passenger airbag (2/3)



A

35770




The marking on the dashboard and label **A** on each side of the passenger sun visor **3** (example of label shown above) remind you of these instructions.



### DANGER

Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an **ACTIVATED** front **AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.

## CHILD SAFETY: deactivating, activating the front passenger airbag (3/3)



### Front passenger airbag activation

You should reactivate the airbag as soon as you remove the child seat from the front passenger seat to ensure the protection of the front passenger in the event of an impact.

**To reactivate the airbag: with the vehicle stationary and the ignition off**, push and turn the lock **1** to the **ON** position.

With the ignition on, you **must** check that the warning light **2** is off.

The front passenger airbag has been activated.



### Operating faults

In the event that the front passenger airbag activation/deactivation system is faulty, child seats must not be fitted to the front seat.

Allowing any other passenger to sit in that seat is not recommended.

Contact your approved Dealer as soon as possible.



### DANGER

Since operation of the front passenger airbag is not compatible with the position of a rear-facing child seat, **NEVER** fit a rear-facing child restraint system in a seat protected by an **ACTIVATED** front **AIRBAG**. This can lead to the **DEATH** of the **CHILD** or **SERIOUS INJURY**.




The passenger airbag must only be activated or deactivated **while the vehicle is stationary** with the ignition

off.

If it is interfered with when the vehicle is being driven, indicator lights




and  will come on.

Switch the ignition off then on again to reset the airbag in accordance with the lock position.

# DRIVING POSITION, LEFT-HAND DRIVE (1/2)

42485






## DRIVING POSITION, LEFT-HAND DRIVER (2/2)

The equipment fitted, described below, **DEPENDS ON THE VERSION AND COUNTRY.**

- 1** Stalk for:
  - direction indicator lights;
  - exterior lights;
  - front fog lights;
  - rear fog lights.
- 2** – Horn,
  - location for driver's air bag.
- 3** Instrument panel.
- 4** Stalk for:
  - windscreen wipers;
  - windscreen washer;
  - trip computer and warning system.
- 5** Ignition switch.
- 6** Multimedia display or touchscreen:
  - seat belt reminder warning light;
  - airbag deactivation warning light;
  - navigation;
  - clock;
  - exterior temperature.
- 7** Centre air vent.
- 8** Controls for ventilation, heating and de-icing.
- 9** Windscreen demister outlet.
- 10** Location for passenger air bag.
- 11** Speaker.
- 12** Side air vent.
- 13** Side window demister outlet.
- 14** Glove box.
- 15** Storage space or accessories socket.
- 16** Hazard warning lights switch.
- 17** Central door locking/unlocking switch.
- 18** ECO mode switch.
- 19** Cigarette lighter or accessories socket.
- 20** Handbrake.
- 21** Gear lever.
- 22** Remote control/location for radio, navigation system.
- 23** Cruise control/speed limiter controls.
- 24** Bonnet release control.
- 25** Controls for:
  - Vertical headlight adjustment;
  - Parking distance control.
- 26** Controls for:
  - Cruise control/speed limiter;
  - additional heating.

# DRIVING POSITION: RIGHT-HAND DRIVE (1/2)

42545




## DRIVING POSITION: RIGHT-HAND DRIVE (2/2)

The equipment fitted, described below, **DEPENDS ON THE VERSION AND COUNTRY.**

- 1** Side window demister outlet.
- 2** Side air vent.
- 3** Speaker.
- 4** Location for passenger air bag.
- 5** Windscreen demister outlet.
- 6** Controls for ventilation, heating and de-icing.
- 7** Centre air vent.
- 8** Multimedia display or touchscreen:
  - seat belt reminder warning light;
  - airbag deactivation warning light;
  - navigation;
  - clock;
  - exterior temperature.
- 9** Stalk for:
  - direction indicator lights,
  - exterior lights;
  - front fog lights;
  - rear fog lights.
- 10** – Horn.
  - Location for driver's air bag.
- 11** Instrument panel.
- 12** Stalk for:
  - windscreen wipers;
  - windscreen washer;
  - trip computer and warning system.
- 13** Ignition switch.
- 14** Cruise control/speed limiter main control.
- 15** Additional heating switch.
- 16** Parking distance control switch.
- 17** Headlight adjustment control.
- 18** Cruise control/speed limiter controls.
- 19** Location for radio, navigation system.
- 20** Gearstick.
- 21** Handbrake.
- 22** ECO mode switch.
- 23** Cigarette lighter or accessories socket.
- 24** Door electric locking/unlocking switch.
- 25** Hazard warning lights switch.
- 26** Storage space or accessories socket.
- 27** Glove compartment.
- 28** Bonnet release control.

# STEERING WHEEL/POWER-ASSISTED STEERING



## Steering wheel height adjustment

Pull lever **1** and move the steering wheel to the required position; push lever to lock the steering wheel.

Make sure that the steering wheel is correctly locked.



For safety reasons, only adjust the steering wheel when the vehicle is stationary.

## Power-assisted steering

The variable power-assisted steering system is equipped with an electronic control system which alters the level of assistance to suit the vehicle speed.

Steering is made easier during parking manoeuvres (for added comfort) while the force needed to steer increases progressively as the speed rises (for enhanced safety at high speeds).



Never switch off the ignition when travelling downhill, and avoid doing so in normal driving (assistance is not provided).

Never leave the steering wheel on full lock when the vehicle is stationary.

With the engine switched off, or if there is a system fault, it is still possible to turn the steering wheel. The force required will be greater.

A noise may be heard when the steering wheel is moved quickly. This is normal.

# WARNING LIGHTS (1/3)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



## Instrument panel A

In some cases, the appearance of a warning light is accompanied by a message.



Warning light **STOP** requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an approved Dealer.



Main beam headlight tell-tale light



Dipped beam headlight tell-tale



Front fog light tell-tale light



Rear fog light tell-tale



Left-hand direction indicator tell-tale light



Right-hand direction indicator tell-tale light



Vehicle ready for driving warning light

This comes on when the engine is started.



Charging cord plugged in warning light


This comes on when the charging cord is plugged into the vehicle.



12V battery charge warning light

If it comes on when you are driving, it indicates that the circuit is overcharged or has discharged. Stop and consult an approved Dealer as soon as possible.



The  warning light means you should **drive very carefully** to an approved Dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.

## WARNING LIGHTS (2/3)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



### **STOP** STOP light

This lights up when the ignition is switched on and goes out as soon as the engine is started. It comes on with other warning lights and/or messages.

It requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it.

Contact an approved Dealer.

### **Brake circuit fault warning light**

If it comes on during braking and is accompanied by the **STOP** warning light and a beep, it indicates that the fluid level in the circuit is low or that there is a braking system fault. Stop as soon as traffic conditions allow and contact an approved Dealer.

### **Warning light**

This lights up when the ignition is switched on and goes out as soon as the engine is started. It can light up in conjunction with other warning lights and/or messages on the instrument panel.

It means you should **drive very carefully** to an approved dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.

### **Cruise control and speed limiter indicator lights**

Refer to the information on the “Speed limiter” and “Cruise control” in Section 2.

### **Indicator light Airbag**

This comes on when the ignition is switched on and goes out after a few seconds. If it does not come on when the ignition is switched on or if it flashes, there is a fault in the system. Contact an approved Dealer as soon as possible.

### **Low fuel level or additional heating warning light**

This comes on when the ignition is switched on and goes out after a few seconds. If it comes on while driving, accompanied by a beep, this means the imminent end of fuel power for the additional heating.

### **Seat belt reminder light**

Depending on the vehicle, it is displayed on the instrument panel or on the central display of the dashboard. It remains on when the engine is started if your seat belt is not fastened. A beep sounds at a low volume for 30 seconds, then at a high volume for 90 seconds.

## WARNING LIGHTS (3/3)

The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



### **Low traction battery level warning light**

This comes on when the traction battery charge level has reached the reserve threshold. Please see the information on “Displays and indicators” in Section 1.

### **Electrotechnical system warning light**

If this comes on while driving, it indicates an electrotechnical fault relating to the “400V” electrical circuit. Please contact an authorised dealer as soon as possible.

### **Electrotechnical system warning light**

When the blue warning light comes on, this indicates that the traction battery temperature is too low.

When the orange warning light comes on, this means the traction battery or the motor temperature is too high.

**If either of these warning lights come on, this may lead to reduced vehicle performance.**

Opt for a calmer driving style.

### **Anti-lock braking warning light**

This lights up when the ignition is switched on and goes out after a few seconds.

If it does not go out after the ignition is switched on, or lights up when driving, there is a fault with the ABS. Braking will then be as normal, without the ABS system.

Contact an approved Dealer as soon as possible.

### **Low fuel level or additional heating warning light**

This comes on when the ignition is switched on and goes out after a few seconds. When driving, if it comes on together with a beep, the minimum fuel level has been reached.

### **Driving correction device warning light**


Please refer to the information on “Driver correction devices and aids” in Section 2.

### **Tyre pressure loss warning**

Please refer to the information on the “Tyre pressure loss warning” in Section 2.

# DISPLAYS AND INDICATORS (1/3)


The presence and operation of the display and indicators **DEPENDS ON THE LEVEL OF EQUIPMENT AND THE COUNTRY.**



## Speedometer 1

Vehicle speed is limited to approximately 80 mph (130 km/h).

Depending on your vehicle, this speed can be permanently limited to a set value.



## Overspeed buzzer

Depending on the vehicle, a beep sounds for 10 seconds approximately every 40 seconds as long as the vehicle is travelling at over 72 miles per hour (120 km/h).

**Note:** the desired speed may be programmed; consult an approved Dealer.


## Multifunction display 2

Please refer to the information on the "Trip computer: general information" in Section 1.

## Charge level 3


The gauge indicates the level of energy remaining.

## Reserve threshold 5

This indicates that the battery is at approximately 12% charge. The warning light  comes on and a beep sounds.

To optimise your range, please see the information on "Recommendations: saving energy" in Section 2.

## Immobilisation threshold imminent 4

This indicates that the battery is at approximately 6% charge. A beep is repeated every 10 seconds and warning light  flashes.

The message "Limited performance" may also be displayed on the instrument panel.


Motor performance gradually decreases until the vehicle comes to a stop.

Please see the information on "Towing: breakdown recovery" in Section 5.




## DISPLAYS AND INDICATORS (2/3)

The presence and operation of the display and indicators **DEPENDS ON THE LEVEL OF EQUIPMENT AND THE COUNTRY.**



### Charge meter 6

Please refer to the information on the “Charge meter” in Section 2.



### “Energy recovery” usage zone A

The needle tells you that the vehicle is generating energy and the traction battery is being recharged (under braking or going downhill).

### “Neutral” position B


The needle tells you that you are at nil consumption (the vehicle is at a standstill without consuming energy).

### “Consumption” usage zone C

The needle tells you the energy consumption (as soon as you depress the accelerator pedal).

## DISPLAYS AND INDICATORS (3/3)

The presence and operation of the display and indicators **DEPENDS ON THE LEVEL OF EQUIPMENT AND THE COUNTRY.**



### Display selection keys 5 or 6

Depending on the vehicle, pressing the button repeatedly enables the information on the display to be selected and the trip mileage recorder to be reset (for this, the trip mileage must be selected on the display).

#### - Display selection

Press briefly to move from the total mileage to the trip mileage and vice versa.

#### - Resetting the trip mileage recorder

Once trip mileage has been selected on the display, press and hold the button.

#### Multifunction display

Total mileage recorder.

Trip mileage recorder.

Setting the time.

OR

Trip computer and warning system



Refer to the information on the "Trip computer" in Section 1.

## TRIP COMPUTER: general information (1/2)




### Trip computer and warning system A

Depending on the vehicle, this includes the following functions:

- distance travelled;
- journey parameters;
- information messages;
- operating fault messages (associated with the  warning light);
- warning messages (connected to the  warning light).

All these functions are described on the following pages.




### Display selection keys 1 and 2

Scroll through the following information upwards (button **1**) or downwards (button **2**) by pressing briefly and successively (the display depends on the vehicle equipment and country).

- Total mileage and trip mileage recorder;
- journey parameters:
  - Total energy consumption since the last reset;
  - average energy consumption;
  - current energy consumption;
  - Total energy consumption since the vehicle first entered into service;
  - estimated range;
  - distance travelled;
  - average speed.
- mileage before service;
- cruise control and speed limiter programmed speed;
- Reset the tyre pressure
- trip log, operating faults and information message readout.

## TRIP COMPUTER: general information (2/2)



### Trip mileage resetting

With “trip mileage recorder” selected on the display, press button **1** or **2** until the mileage recorder resets to zero.

### Resetting the journey parameters (reset button)

With one of the journey parameters selected on the display, press button **1** or **2** until the display resets.

### Automatic resetting of the journey parameters

Resetting occurs automatically when the maximum value of any of the parameters is exceeded.

### Resetting the estimated range

Press and hold one of the buttons **1** or **2**. Estimated range is calculated in proportion to the traction battery charge level.

### Reading energy consumption values

Some vehicle equipment items consume energy: the energy consumed by the vehicle may therefore differ from the energy consumed on the electric counter.








### Interpreting some of the values displayed after resetting

Average energy consumption and speed are all the more stable and reliable as the distance travelled from the last reset is great.

The estimated range displayed after reset may not be indicative of your true range (which depends on your driving style): this is because the on-board computer is programmed with a predefined consumption over an average of around 18 miles (30 km). This is gradually replaced by your true consumption as the travel distance increases: the display will be all the more stable and reliable as the distance travelled since the last reset is great.







# TRIP COMPUTER AND WARNING SYSTEM: journey parameters (1/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
<p>101778 km</p> <p>112,4 km</p>	<p> <b>a) Total mileage and trip mileage recorder.</b></p>
<p>Consumption</p> <p>20 kWh</p> <p></p>	<p> <b>b) Journey parameters.</b> <b>Energy</b> consumed since the last reset.</p>
<p>Average</p> <p>18,5 kWh/100km</p> <p></p>	<p> <b>Average energy consumption</b> since the last reset. The value is displayed after having travelled at least 400 metres since the last reset.</p>
<p>INSTANT CONSO</p> <p>+ 12 kW</p> <p></p>	<p> <b>Current energy consumption.</b></p>


## TRIP COMPUTER AND WARNING SYSTEM: journey parameters (2/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
<p data-bbox="263 303 334 329">Range</p> <p data-bbox="263 381 334 407">118 km</p>	<p data-bbox="541 337 613 378"></p> <p data-bbox="644 311 1097 337"><b>Estimated range with remaining energy.</b></p> <p data-bbox="644 351 1427 400">The information disappears when the battery is at less than approximately 4%.</p>
<p data-bbox="250 456 346 482">Distance</p> <p data-bbox="258 501 338 527">522 km</p> <p data-bbox="247 561 341 586"></p>	<p data-bbox="541 505 613 546"></p> <p data-bbox="644 512 1062 538"><b>Distance travelled</b> since the last reset.</p>
<p data-bbox="250 628 346 654">Average</p> <p data-bbox="254 673 343 698">48 km/h</p> <p data-bbox="247 732 341 758"></p>	<p data-bbox="541 676 613 717"></p> <p data-bbox="644 673 1146 722"><b>Average speed</b> since the last reset. The value is displayed after driving 400 metres.</p>
<p data-bbox="228 818 368 844">Consumption</p> <p data-bbox="250 893 346 919">487 kWh</p>	<p data-bbox="541 848 613 890"></p> <p data-bbox="644 856 1226 882"><b>Total energy usage</b> since vehicle first entered service.</p>

## TRIP COMPUTER AND WARNING SYSTEM: journey parameters (3/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected
<div data-bbox="107 273 508 426" style="border: 1px solid black; padding: 10px; text-align: center;">SERVICE IN  1936 km</div>	<p data-bbox="662 277 873 303"><b>c) Service interval.</b></p> <p data-bbox="689 316 1427 367">Distance remaining until the next service (displayed in kilometres), then when the service nears, several scenarios are possible:</p> <ul data-bbox="689 370 1427 544" style="list-style-type: none"><li data-bbox="689 370 1427 449">– distance/time remaining less than <b>900 miles (1,500 km)</b> or <b>one month</b>: the message “SERVICE IN” is displayed, together with the nearest distance or time;</li><li data-bbox="689 463 1427 544">– interval equal to <b>0 miles (0 km)</b> or <b>service date reached</b>: the message “SERVICE PROMPTLY” is displayed accompanied by warning light .</li></ul> <p data-bbox="689 557 1230 583">The vehicle requires a service as soon as possible.</p>
<p data-bbox="84 652 1052 678"><b>Resetting the display after the service in accordance with the maintenance schedule.</b></p> <p data-bbox="84 678 1427 704">The service interval must only be reset after a service which complies with the recommendations in the maintenance schedule.</p> <p data-bbox="84 715 1427 766"><b>Special note:</b> to reset the service interval, press and hold one of the display reset buttons for approximately 10 seconds until the display shows the mileage permanently.</p>	

## TRIP COMPUTER AND WARNING SYSTEM: journey parameters (4/4)

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

Examples of selections	Interpreting the display selected							
<table border="1"><tr><td data-bbox="87 266 394 381">SPEED LIMITER 90 km/h</td><td data-bbox="420 266 727 591" rowspan="2"></td></tr><tr><td data-bbox="87 389 394 568">CRUISE CONTROL 90 km/h</td></tr><tr><td data-bbox="87 591 394 703">TYRE PRESSURE ACQUISITION</td><td data-bbox="420 591 727 703">SEt PP</td></tr><tr><td data-bbox="87 785 394 927">NO MESSAGE AVAILABLE</td><td data-bbox="420 785 727 927"></td></tr></table>	SPEED LIMITER 90 km/h		CRUISE CONTROL 90 km/h	TYRE PRESSURE ACQUISITION	SEt PP	NO MESSAGE AVAILABLE		<p><b>d) Cruise control/speed limiter programmed speed.</b> Please refer to the “Cruise control/speed limiter” information in Section 2.</p> <p><b>e) Reset the tyre pressures.</b> Please refer to the information on the “Tyre pressure loss warning” in Section 2.</p> <p><b>f) Trip log.</b> Successive display: – information messages; – operating fault messages. Refer to the information on the “Trip Computer: information messages” and “Trip Computer: operating fault messages” in section 1.</p>
SPEED LIMITER 90 km/h								
CRUISE CONTROL 90 km/h								
TYRE PRESSURE ACQUISITION	SEt PP							
NO MESSAGE AVAILABLE								



# TRIP COMPUTER AND WARNING SYSTEM: information messages


## Information messages


These can help in the vehicle starting phase, or give information about a selection or a driving status.

Examples of information messages are given in the following pages.

Examples of messages	Interpretation of messages
"CHARGE REMAIN 02:10"	Indicates the time remaining before a full charge.
"NO MESSAGE AVAILABLE"	No warning is stored.
"BRAKE THE VEHICLE"	Follow these instructions: risk of damage to the motor.
"BOILER STOPPED"	Indicates a halt to the additional heating due to lack of fuel in the tank.
"PERFORMANCE LIMITED"	Indicates deterioration of vehicle performance.
"BATT CHARGE IMPOSSIBLE"	Indicates that the charging is prohibited by your battery rental organisation. Rectify the situation.
"AUTO LIGHTS DEACTIVATED"	Indicates that the automatic lights function is deactivated.

## TRIP COMPUTER AND WARNING SYSTEM: operating fault messages

These appear with the  warning light and mean that you should drive very carefully to an approved Dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.

They disappear when the display selection key is pressed or after several seconds and are stored in the computer log. The  warning light stays on. Examples of operating fault messages are given on the following pages.

Examples of messages	Interpretation of messages
“BRAKES TO BE CHECKED”	Indicates wear or the need to check the braking system.
“BATT CHARGE IMPOSSIBLE”	Indicates a fault on the traction battery recharge system.
“CHECK AUTO LIGHTS”	Indicates a fault in the automatic lights operation.


## TRIP COMPUTER AND WARNING SYSTEM: warning message

These appear with the **STOP** warning light and require you to stop immediately, for your own safety, as soon as traffic conditions allow. Stop your engine and do not restart it. Contact an approved Dealer.

Examples of warning messages are given in the following pages. **Note:** the messages appear on the display either individually or alternately (when there are several messages to be displayed), and may be accompanied by a warning light and/or a beep.

Examples of messages	Interpretation of messages
« STEERING FAULT »	Indicates a fault in the vehicle's power assisted steering.
« ELEC FAULT DANGER »	Indicates a fault in the electrical system.
« ELEC. MOTOR FAULT »	Indicates that the vehicle is losing power.
« BRAKING FAULT »	Indicates a fault in the braking system.
« TYRE PUNCTURE »	Indicates that at least one wheel is punctured or severely underinflated.

# CLOCK AND EXTERIOR TEMPERATURE



With the ignition on, the time and, depending on the vehicle, exterior temperature are displayed.

## Setting the time

### Resetting the clock **A** (depending on vehicle)

Display the “Clock” page on the instrument panel by pressing one of the buttons on stalk **1**.



For safety reasons, carry out any adjustments when the vehicle is not being driven.

After two seconds, the hours and minutes start flashing.

Press and hold the bottom button to enter the hour setting mode.

When only the hours flash, press the top button to scroll through them.

Press and hold the bottom button to enter the minute setting mode.

When only the minutes flash, press the top button to scroll through them.

Confirm by pressing and holding the bottom button on stalk **1**.

### Vehicles equipped with a navigation system, radio, etc.

Refer to the equipment instructions for the special features.

## Exterior temperature

On equipped vehicles, the exterior temperature is displayed at **A**. If it is between  $-3^{\circ}\text{C}$  and  $+3^{\circ}\text{C}$ , the  $^{\circ}\text{C}$  characters flash (signalling a risk of ice).


If the electrical supply is cut (battery disconnected, broken supply wire, etc.), the clock will lose its time setting. The time must then be set.



### Exterior temperature indicator


As ice formation is related to climatic exposure, local air humidity and temperature, the external temperature alone is not sufficient to detect ice.

## REAR-VIEW MIRRORS



### Interior rear view mirror

The interior rear view mirror is adjustable. When driving at night, tilt lever **1** to avoid being dazzled by the headlights of the vehicle behind.



### Door mirrors with electrical adjustment

With the ignition on, turn button **2**:

- position **A** to adjust the left-hand door mirror;
- position **C** to adjust the right-hand door mirror.

**B** is the inactive position.

### Heated door mirrors

When the engine is started, mirror de-icing is activated with the rear screen de-icing/demisting.

### Folding door mirrors

Move button **2** to position **D** to fold the door mirrors in. To reset them for driving, return to position **B**.

If you fold the door mirrors in manually before resetting them to driving position **B**, you must first turn button **2** to position **D**.

# AUDIBLE AND VISUAL SIGNALS




## Horn

Press one of points 2.

## Direction indicators

Move stalk 1 parallel to the steering wheel and in the direction you are going to turn.

When driving on the motorway, the steering wheel is not often turned enough to return the stalk automatically to 0.




There is an intermediate position in which the switch may be held when changing lanes.

You can also briefly place stalk 1 in the intermediate position, causing the indicator light to flash three times.

When the stalk is released, it automatically returns to 0.

## Headlight flasher

Pull stalk 1 towards you to flash the headlights.




## Hazard warning lights

Pressing switch 3 illuminates all four direction indicators and the side-mounted indicator lights simultaneously. It must only be used in an emergency to warn other drivers that you have had to stop in an area where stopping is prohibited or unexpected, or that you are obliged to drive under special conditions.

## EXTERNAL LIGHTING AND SIGNALS (1/3)

43299



### Side lights

Turn the end of stalk **1** until the symbol is opposite mark **2**.

The instrument panel will light up.



### Dipped beam headlights

#### Manual operation

Turn the end of stalk **1** until the symbol is opposite mark **2**. This indicator light on the instrument panel comes on.

#### Automatic operation (depending on vehicle)

When the engine is started, the dipped beam headlights switch on or off automatically depending on the brightness of the light outside, without any action on stalk **1**.

This function can be deactivated or reactivated.

- **To switch it on:** with the ignition on and the vehicle stationary, press and hold button **3** for at least four seconds. Depending on the vehicle, the message “lights ON” appears on the instrument panel.
- **To deactivate:** with the ignition on and the vehicle stationary, press and hold button **3** for at least four seconds. Depending on the vehicle, the message “lights OFF” appears on the instrument panel.



### Main beam headlights

With stalk **1** in dipped beam headlights position, move the stalk towards you. The indicator light on the instrument panel then lights up.

To return to the dipped beam headlight position, pull the stalk towards you again.



Before driving at night: check the electrical equipment is operating correctly and adjust your headlights (if your vehicle is not carrying its normal load). As a general precaution, check that the lights are not obscured (by dirt, mud, snow or objects being transported).

## EXTERNAL LIGHTING AND SIGNALS (2/3)

### “See-me-home lighting” function


(depending on vehicle)

This function (useful, for example, when opening a gate, garage, etc.) enables you to switch the dipped headlights on momentarily.

With the ignition off and the headlights off, pull stalk **1** towards you: the dipped beam headlights come on for approximately sixty seconds.

This action may be carried out no more than four times for a maximum lighting period of four minutes.

To switch off the lights before they switch off automatically, turn the end of stalk **1** then bring it back to position 0, or switch on the ignition.



43299

### Lights-on reminder buzzer

A warning beep sounds when the driver's door is opened to warn you that the lights are still on.


### Switching off the lights

There are two possibilities:

- manually, move stalk **1** to its original position;
- automatically, the lights are switched off when the engine is stopped, the driver's door is opened or, depending on the vehicle, when the vehicle is locked. In this case, the next time the engine is started the lights will be switched back on according to the position of the ring **2**.



## EXTERNAL LIGHTING AND SIGNALS (3/3)



43299

### **Front fog lights** (depending on vehicle)

The side lights or dipped beam headlights must be on.

Turn ring **5** on stalk **1** until the symbol is opposite mark **4**, then release it. This indicator light on the instrument panel comes on.

### **Rear fog light**

The front fog lights and the side lights or dipped beam headlights must be on.

Turn ring **5** on stalk **1** until the symbol is opposite mark **4**, then release it. This indicator light on the instrument panel comes on.


To avoid inconveniencing other road users, remember to switch off the rear fog light when it is no longer needed.

### **Turning off the fog lights**

Turn ring **5** again to position mark **4** opposite the symbol for the light you wish to switch off.

Switching off the exterior lights or the ignition switches off the front and rear fog lights.

## HEADLIGHT BEAM ADJUSTMENT (1/2)




Control knob **1** is used to adjust the height of the headlight beams according to the load.

Turn control knob **1** downwards to lower the headlights and upwards to raise them.

Unladen, control knob **1** should be at 0.

When the vehicle is partially or completely laden, the headlight beam should be set to light the road at between 50 and 100 metres. Then use positions 1 to 4 on the control knob.




**A** Poor adjustment: the lights are set too high and could dazzle other drivers. Turn the control knob downwards to lower the beam.

**B** Good adjustment: the beam's maximum range is between 50 and 100 metres.

## HEADLIGHT BEAM ADJUSTMENT (2/2)

When driving on the left in a left-hand drive vehicle (or vice versa), you must adjust your lights temporarily during your stay.



38494


### Temporary adjustment

Open the bonnet and identify the marking **B** next to one of the front headlight projectors.


For each headlight, using a screwdriver, turn the screw **1** by a quarter turn towards the - symbol to lower the beams.

Return to the starting point once your trip is over: turn the screw **1** by a quarter turn towards the + symbol to raise the beams.

# FRONT WINDSCREEN WASHER, WIPER (1/2)



27259



36226

## Windscreen wiper

With the ignition on, move stalk **1** parallel to the steering wheel:

### A Park

### B Intermittent wiping

The wipers will pause for several seconds between sweeps. It is possible to change the time between sweeps by turning ring **2**.

### C Normal wiping speed

### D Fast wiping speed

## Special note

**When the vehicle is being driven**, the wiping speed slows down whenever the vehicle stops. For example, fast wiping speed will slow to normal wiping speed. As soon as the vehicle moves off, wiping will return to the speed originally selected.

If stalk **1** is operated, it overrides and cancels the automatic function.

If for any reason the wipers are jammed (e.g. frozen to windscreen by ice etc.), the system will automatically cut the power supply to the wipers.

## Automatic wiper function (depending on vehicle)

With the engine running, move stalk **1**.

### A Park

### B Automatic wiper function


When this position is selected, the system detects the presence of water on the windscreen and triggers wiping at a suitable wiping speed. The triggering threshold and the time between sweeps can be adjusted by turning ring **2**.

**NB:** in foggy weather or during snowfalls, the wiping is not automatically triggered and remains under the driver's control.

### C Normal wiping speed

### D Fast wiping speed

## FRONT WINDSCREEN WASHER, WIPER (2/2)



### Windscreen wiper

**With the ignition on**, pull stalk **1** towards you.

A brief pull will trigger a single sweep of the wipers, in addition to the windscreen washer.

A longer pull will trigger three sweeps of the wipers followed, a few seconds later, by a fourth, in addition to the windscreen washer.

In freezing or snowy weather, ensure they are not stuck to the windscreen (including the central area located behind the interior rear-view mirror) before starting the wipers (risk of motor overheating).



Before any action on the windscreen (washing the vehicle, de-icing, cleaning the windscreen, etc.) return stalk **1** to position **A** (off).

**Risk of injury and/or damage.**

### Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:


- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

Replace wiper blades as soon as their performance starts to diminish: Approximately every year (refer to the information on “Wiper blades” in section 5).

### Precautions for using the wipers

- In freezing or snowy weather, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

# REAR WINDSCREEN WASHER, WIPER



27259



## Speed-dependent rear screen wiper with

### timer

(depending on vehicle)

Turn the end of stalk **1** to position the symbol opposite mark **2**.

Wiping frequency varies with speed.

### Special note

If the windscreen wipers are operational when you select reverse gear, the rear screen is wiped intermittently.



## Rear screen wash/wipe (depending on vehicle)

Turn the end of stalk **1** to position the symbol opposite mark **2**.

When the stalk is released, it returns to the rear screen wiper position.

Do not use the wiper arm to open or close the tailgate.



Before any action involving the rear screen (washing the vehicle, de-icing, cleaning etc.) return stalk **1** to the stop position.

**Risk of injury and/or damage.**

## Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:


- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

Replace wiper blades as soon as their performance starts to diminish: Approximately every year (refer to the information on “Wiper blades” in section 5).

## Precautions for using the wipers

- In freezing or snowy weather, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

## ADDITIONAL HEATING TANK



**Useful capacity of fuel tank: 13 litres approx.**

To open the fuel filler flap, place your finger into recess **C**.

Use the ignition key to open cap **B**.



Do not operate the additional heating when the vehicle fuel tank is being filled.

### Fuel grade

**Use a high-grade diesel** that complies with the legislation in force in each country and which **must** conform to the specifications given on the label on cover **A**.

Fuel odours and smoke may be present after a long period without using the additional heating.



### Persistent smell of fuel

If you notice a persistent smell of fuel you should:

- stop the vehicle as soon as traffic conditions allow and switch off the ignition;
- switch on the hazard warning lights and ask your passengers to leave the vehicle and to keep away from traffic;
- contact an approved Dealer.

### Diesel filling

- Insert the nozzle so that the valve is open and **fully** insert the nozzle before engaging it in order to fill the tank (risk of splash-back).
- Keep the nozzle in this position throughout the entire filling operation.

When the pump cuts out automatically at the end of the filling procedure, a maximum of two further filling attempts may be made so as to leave sufficient room for expansion.



### Fuel filler cap: this is of a special type.

If you have to replace it, make sure it is identical to the original cap. Contact an approved Dealer. Never place the cap near a source of heat or flame.

Do not wash the filler area with a high-pressure washer.






# **Section 2: Driving**

***(Advice on use relating to fuel economy and the environment)***

Starting, stopping the engine . . . . .	2.2
Gear control . . . . .	2.4
Handbrake . . . . .	2.6
Driving advice, ECO-driving . . . . .	2.7
Vehicle range: advice . . . . .	2.9
Environment . . . . .	2.11
Tyre pressure loss warning . . . . .	2.12
Driver correction devices and aids . . . . .	2.16
Speed limiter . . . . .	2.19
Cruise control . . . . .	2.22
Parking distance control . . . . .	2.26
Reversing camera . . . . .	2.28

## STARTING, STOPPING THE ENGINE (1/2)



### “Stop and steering lock” position St

To unlock: turn the key and the steering wheel slightly.

To lock: remove the key and turn the steering wheel until the steering column locks.

### “Accessories” position A

When the ignition is switched off, any accessories (radio, etc.) will continue to function.



### “On” position M

The ignition is switched on:

### Start position D

#### Starting the engine

- Move lever **1** to position **P** only ;
- turn the key to position **D** and then release it.


Warning light  may flash on the instrument panel, along with a beep. As soon as light  stops flashing and the beep stops, the vehicle is ready to drive.

The vehicle can only be started if the charging cord is unplugged from the vehicle.

The vehicle can only be started if the selector lever is at **P**. Please see the information on “Gear control” in Section 2.

## STARTING, STOPPING THE ENGINE (2/2)

### Stopping the engine

With the engine running, turn the key back to the “Stop” position **St**. Warning light  goes out.



Never switch off the ignition before the vehicle has come to a complete stop.

Switching off the engine disables the assistance equipment: brakes, power-assisted steering, etc., and the passive safety devices such as airbags and pretensioners.



### **Driver's responsibility when parking or stopping the vehicle**


Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## GEAR CONTROL (1/3)



Operates in a similar manner to an automatic gearbox.

### Selector lever 1

The display **A** on instrument panel indicates the gear lever position as **3**.

- P** : Park
- R** : Reverse
- N** : Neutral
- D** : Forward

33484




### Operation

Keeping your foot on the brake pedal and with the selector lever **1** in position **P**, turn the ignition.

Start the motor.

To move out of position **P**, you must depress the brake pedal before pressing unlocking button **2**.

With your foot on the brake pedal (warning light  in display **A** goes out), move the lever out of position **P**.

**Only engage D or R when the vehicle is stopped, with your foot on the brake and the accelerator pedal released.**

### Driving

Put lever **1** into position **D**.

### Hill start

For hill starts, especially after a maximum traction battery charge and for the first few miles, we recommend using the handbrake.

While driving, press the accelerator pedal to achieve the desired speed.

### Reverse

Put lever **1** into position **R**.

The reversing lights will come on as soon as reverse gear is selected (with the ignition on).

The vehicle can only start if the gear selector is in position **P**.

The vehicle can only be started if the charging cord is unplugged from the vehicle.

## GEAR CONTROL (2/3)

### Parking the vehicle

When the vehicle is stationary, move the lever to **P** position while keeping your foot on the brake pedal: the control is in neutral and the drive wheels are mechanically locked by the driveshaft.

**Apply the handbrake.**

**P** position must only be engaged when the vehicle is stationary.




In the event an impact to the underside of the vehicle (e.g.: striking a post, raised kerb or other street furniture), this may result in damage to the vehicle (e.g.: twisted axle), the electrical circuit or the traction battery.

Do not touch the circuit elements or any fluids or liquids.

To prevent any risk of accident, have your vehicle checked by an authorised dealer.

**Risk of serious injury or electric shock and risk to life.**

## GEAR CONTROL (3/3)/HANDBRAKE



**When activated**, in the event that the lever is stuck in **P**, depress the brake paddle. It is possible to free the lever manually. To do this, unclip the cover at the base of the lever and simultaneously press at location **4** and on the unlocking button **6** on the lever.

### Handbrake

#### To release:

Pull the lever **5** up slightly, press button **6** and then lower the lever to the floor.

#### To apply:

Pull upwards, check that the vehicle is properly immobilised.



Make sure that the handbrake is properly released when driving (red indicator light off), otherwise overheating, or even damage, may occur.



When stationary and depending on the slope and/or vehicle load, it may be necessary to pull up the handbrake at least two extra notches and engage position **P**.

## DRIVING ADVICE, ECO-DRIVING (1/2)


The vehicle range depends on vehicle usage conditions, equipment fitted and the user's driving style. To optimise the energy consumption, please refer to the following advice.

Depending on the vehicle, you will be provided with functions which enable you to lower the energy consumption:

- ECO mode, activated by the ECO button;
- charge meter.

### ECO mode

The ECO function optimises vehicle range by limiting engine performance. It acts upon certain power consuming systems in the vehicle (heating, air conditioning, power-assisted steering etc.) and on certain driving actions (acceleration, cruise control, deceleration etc.).



#### Activating the function


Press switch **1**.

Warning light **2** will come on the instrument panel and the integrated warning light on the switch will light up.

While driving, it is possible to exit the ECO mode temporarily in order to improve engine performance.

To do this, press the accelerator pedal firmly and fully.

33485



ECO mode is reactivated when you take pressure off the accelerator pedal.


#### Disabling the function

Press switch **1**.

Warning light **2** and the integrated warning light on the switch will go out.

The cruise control switches to standby each time the ECO mode is activated or deactivated. Please refer to the information on "Cruise control/speed limiter: cruise control function" in Section 2.

## DRIVING ADVICE, ECO-DRIVING (2/2)




### Charge meter

(on the instrument panel)

The charge meter gives the driver a real-time view of the vehicle's energy recovery or consumption.

#### “Energy recovery” usage zone A

When driving, if you lift your foot off the accelerator pedal or apply the brake, the motor generates electrical current during deceleration, and this energy is used to slow down the vehicle and recharge the traction battery.




### Energy recovery features

The motor generates a more significant engine brake than a conventional vehicle.

After a maximum charge for the traction battery and during the first few miles when driving the vehicle, the engine brake is temporarily reduced. Please adapt your driving style accordingly.

#### “Neutral” 0 usage zone

Indicates nil consumption.



### “Recommended consumption” usage zone B

The traction battery supplies the electrical energy required for the motor to move the vehicle.

### “Consumption not recommended” usage zone C

Indicates high energy consumption.



## VEHICLE RANGE: recommendations (1/2)

In real usage, the range of an electric vehicle may vary depending on several factors over which you have partial control, which may make a considerable difference to the vehicle range. These factors are:

- speed and driving style;
- type of road;
- heating level;
- tyres;
- vehicle loading.

Furthermore, activating ECO mode enables the vehicle to automatically take charge of all energy consumers (engine power, etc.) in order to reduce their consumption to the fullest possible extent. Please refer to the information on “ECO-driving” in Section 2.

### Speed and driving style

High speeds will reduce your vehicle’s range.

A “sporty” driving style reduces your vehicle range: opt for a “lighter” driving style.


34630



#### Advice:

- drive at a constant speed;
- adapt your driving style to avoid excessive energy consumption. Please refer to the “Charge meter” information in Section 2;
- in order to recover energy, anticipate traffic changes and lift your foot off the accelerator pedal in advance. Please refer to the “Charge meter” information in Section 2;
- use ECO mode by default (see the paragraph on “ECO mode function” in Section 2).

34628



### Road type

Do not try to maintain the same speed up a hill; accelerate no more than you would on the level. Keep your foot in the same position on the accelerator pedal.

## VEHICLE RANGE: recommendations (2/2)

34629




### Heating levels

The use of heating or air conditioning reduces vehicle range.

Before using the vehicle, opt for “air conditioning programming” mode to maintain vehicle range (please refer to the information on “Heating, air conditioning programming” in Section 3).

When driving, minimise the use of heating and air conditioning and opt for using the additional heating (please refer to the information on “Additional heating” in Section 3).



### Tyres

An under-inflated tyre increases energy consumption. Comply with the specified tyre pressures for your vehicle.

When driving, use tyres made by the same manufacturer, with the same dimensions, type and structure as the original tyres. The use of non-regulation tyres significantly reduces vehicle range.

Please see the information on “Tyre pressure” in Section 4.

### Vehicle loading

Avoid pointlessly overloading your vehicle.

## ENVIRONMENT

Your vehicle has been designed with respect for the **environment** in mind for its entire service life: during production, use and at the end of its life.

### Manufacture

Your vehicle has been manufactured at a factory which complies with a policy to reduce the environmental impact on the surrounding areas (reduction of water and energy consumption, visual and noise pollution, atmospheric emissions and waste water; sorting and re-using waste).

### Please make your own contribution towards protecting the environment too

- Worn parts replaced in the course of routine vehicle maintenance (battery, air filter, batteries, etc.) must be disposed of through specialist organisations.
- At the end of the vehicle's service life, it should be sent to approved centres to ensure that it is recycled.
- In all cases, comply with local legislation.


### Recycling

Your vehicle is 85% recyclable and 95% recoverable.

To achieve these objectives, many of the vehicle components have been designed to enable them to be recycled. The materials and structures have been carefully designed to allow these components to be easily removed and reprocessed by specialist companies.

In order to preserve raw material resources, this vehicle incorporates numerous parts made from recycled plastics or renewable materials (vegetable or animal-derived materials such as cotton or wool).


# TYRE PRESSURE LOSS WARNING (1/4)



When fitted to the vehicle, this system notifies the driver if one or more tyres lose pressure.

## Operating principle

Each wheel (except for the emergency spare wheel) has a sensor in the inflation valve which periodically measures the tyre pressure while driving.

Warning light  1 comes on to alert the driver in the event of insufficient pressure (deflated wheel, punctured tyre, etc.).

## Resetting the standard level for the tyre pressures

This should be done:

- when the standard tyre pressure needs to be changed to adapt to usage conditions (empty, carrying a load, motorway driving, etc.);
- after swapping a wheel (however this practice is not recommended);
- after changing a wheel.

It should always be done after checking the tyre pressure of all four tyres when cold.

Tyre pressures must correspond to the current usage of the vehicle (empty, carrying a load, motorway driving, etc.).




This function is an additional driving aid.

However, the function does not take the place of the driver. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.

Check the tyre pressures, including the emergency spare wheel, once a month.

## TYRE PRESSURE LOSS WARNING (2/4)



### Resetting procedure

With the ignition on, depending on the vehicle:

- repeatedly press one of the buttons **3** or **4** to select the “TYRE PRESSURE ACQUISITION” function on the display **2**;
- press and hold (around 3 seconds) button **3** or **4** to start initialisation.

The display of the message “TP ACQUISITION LAUNCHED” for around five seconds indicates that the reset request for the tyre pressure reference value has been taken into account.

Or

- repeatedly press the button **3** to select the “SEt PP” function on the display **2**;
- press and hold (around 3 seconds) the button **3** to start initialisation. The flashing, lasting around five seconds, followed by a constant display of the message “SEt PP ” indicates that the reset request for the tyre pressure reference value has been taken into account.

Reinitialisation is carried out after a few minutes' driving.

**Note:** the standard tyre pressure cannot be less than that recommended and indicated on the door frame.

## TYRE PRESSURE LOSS WARNING (3/4)

### Display

The display **2** on the instrument panel informs you of any tyre pressure faults (flat tyre, punctured tyre, etc.).

### CHECK TYRE PRESSURES

The warning light  stays on and, depending on the vehicle, along with the message “CHECK TYRE PRESSURES”.


These indicate that at least one tyre is flat.

Check and, if necessary, readjust the pressures of the four wheels when cold.

The warning light  goes off after a few minutes' driving.

The sudden loss of pressure in a tyre (burst tyre, etc.) cannot be detected by the system.


### TYRE PUNCTURE

The warning light  stays on together with a beep and, depending on the vehicle, the message “TYRE PUNCTURE”.


This message is accompanied by the warning light .


They indicate that at least one wheel is punctured or severely underinflated. Replace it or contact an authorised dealer if it is punctured. Top up the tyre pressure if the wheel is deflated.



Warning light  requires you to stop immediately, for your own safety, as soon as traffic conditions allow.

### CHECK TYRE SENSORS

The warning light  flashes for several seconds, then stays on and, depending on the vehicle, together with the message “CHECK TYRE SENSORS”.

This message is accompanied by the warning light .

They indicate that at least one tyre is not fitted with sensors (e.g. emergency spare wheel). In other cases, contact an authorised dealer.

## TYRE PRESSURE LOSS WARNING (4/4)

### Readjustment of tyre pressures

**The tyre pressures must be adjusted when cold** (please refer to the label located on the edge of the driver's door). If tyre pressures cannot be checked when the tyres are **cold**, the recommended pressures must be increased by **0.2 to 0.3 bar (3 PSI)**.

**Never deflate a hot tyre.**

### Replacing wheels/tyres

This system requires specific equipment (wheels, tyres, hubcaps, etc.). Please see the information on "Tyres" in Section 5.

Contact an approved Dealer to fit new tyres and to find out about available accessories compatible with the system and available from your dealer network: the use of any other accessory could affect the correct operation of the system or damage a sensor.

### Emergency spare wheel

If the vehicle is equipped with an emergency spare wheel, it will not have a sensor. When it is fitted on the vehi-

cle, the warning light  flashes for several seconds, then stays on, together with the warning light . Depending on the vehicle, the message "CHECK TYRE SENSORS" appears on the instrument panel.

### Tyre repair product and inflation kit

Because the valves are specially designed, only use equipment approved by the approved network. Please refer to "Tyre inflation kit" in Section 5.

## DRIVER CORRECTION DEVICES AND AIDS (1/3)

Depending on the vehicle, this is composed of:

- of the **ABS (anti-lock braking system)**;
- **electronic stability program (ESC) with understeer control and traction control**;
- **emergency brake assist**;
- **hill start assistance**.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions.

However, the functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

### ABS (anti-lock braking system)




Under heavy braking, the ABS prevents the wheels from locking, allowing the stopping distance to be managed and keeping control of the vehicle.

Under these circumstances, the vehicle can be steered to avoid an obstacle whilst braking. In addition, this system can increase stopping distances, particularly on roads with low surface grip (wet ground etc.).

You will feel a pulsation through the brake pedal each time the system is activated. The ABS does not in any way improve the vehicle's physical performance relating to the road surface and roadholding. It is still **essential** to follow the rules of good driving practice (such as driving at a safe distance from the vehicle in front, etc.).

In an emergency, apply **firm and continuous pressure** to the brake pedal. There is no need to pump it repeatedly. The ABS will modulate the force applied in the braking system.

### Operating faults:

- if the  warning light on the instrument panel comes on while driving, **braking is still operational**;
- if the  and  warning lights on the instrument panel come on while driving, **this indicates a fault in the braking system**.

In such cases, ABS, ESC and emergency brake assist are also deactivated and, depending on the vehicle, the messages "WARNING: Check ABS", "BRAKES TO BE CHECKED" and "WARNING: Check ESC" appear on the instrument panel.

Consult an approved dealer.



Your braking systems are partially operational. However, **it is dangerous to brake suddenly** and it is essential to stop immediately, as soon as traffic conditions allow. Call an approved Dealer.



## DRIVER CORRECTION DEVICES AND AIDS (2/3)

### Electronic stability program ESC with understeer control and traction control

#### Electronic stability control ESC

This system helps you to keep control of the vehicle in critical driving conditions (avoiding an obstacle, loss of grip on a bend, etc.).

#### Operating principle

A sensor in the steering wheel detects the direction selected by the driver.

Other sensors throughout the vehicle measure the actual direction.

The system compares driver input to the actual trajectory of the vehicle and corrects the trajectory if necessary by controlling the braking of certain wheels and/or engine power. In the event that the system is engaged, indicator light



flashes on the instrument panel.

#### Understeer control

This system optimises the action of the ESC in the case of pronounced understeer (loss of front axle road holding).

#### Traction control


This system helps to limit wheelspin of the drive wheels and to control the vehicle when pulling away accelerating or decelerating.

#### Operating principle

Using the wheel sensors, the system measures and compares the speed of the drive wheels at all times and slows down their over-rotation. If a wheel is starting to slip, the system brakes automatically until the drive supplied becomes compatible with the level of grip under the wheel again.

The system also adjusts the engine speed to the grip available under the wheels, independently of the pressure exerted on the accelerator pedal.

#### Operating faults

When the system detects an operating fault the message “WARNING: Check ESC” and warning light  appear on the instrument panel. In this case, the ESC and traction control system are deactivated.

Consult an approved dealer.

## DRIVER CORRECTION DEVICES AND AIDS (3/3)

### Emergency brake assist

This is an additional system to ABS which helps reduce vehicle stopping distances.

#### Operating principle


The system detects an emergency braking situation. In this case, the braking assistance immediately develops maximum power and may trigger ABS regulation.

ABS braking is maintained as long as the brake pedal is not released.

#### Brake lights come on

Depending on the vehicle, these may flash in the event of sudden deceleration.

### Operating faults

When the system detects an operating fault the message "BRAKING FAULT" appears on the instrument panel along with the  warning light. Please consult an authorised dealer.

### Hill start assistance

Depending on the gradient of the incline, this system assists the driver when starting on a hill. It prevents the vehicle from rolling backwards, depending on the slope, by automatically applying the brakes when the driver lifts his/her foot off the brake pedal to depress the accelerator pedal.

#### System operation

It only operates when the gear lever is in a position other than neutral and the vehicle is completely stationary (brake pedal depressed).

The system holds the vehicle for approximately **2 seconds**. The brakes are then gradually released (the vehicle will move according to the slope).



The hill start assistance system cannot completely prevent the vehicle from rolling backwards in all situations (extremely steep gradients, etc.).

In all cases, the driver may depress the brake pedal to prevent the vehicle from rolling forwards or backwards.

The hill start assistance function should not be used for prolonged stops: use the brake pedal.

This function is not designed to immobilise the vehicle permanently.

If necessary, use the brake pedal to stop the vehicle.


The driver must remain particularly vigilant when driving on slippery or low-grip surfaces and/or on hills.

**Risk of serious injury.**

## SPEED LIMITER (1/3)



The speed limiter function helps you stay within the driving speed limit that you choose, known as the **limit speed**.





### Controls

- 1 Main “On/Off” switch.
- 2 Speed limiter activation, memory and increase (+).
- 3 Decreasing the speed limiter (-).
- 4 Speed limiter function standby (with limited speed memory) (O).
- 5 Activation and recall of memorised limit speed (R).



### Switching on

Press the side switch **1** . Warning light  comes on, lit orange, and the “SPEED LIMITER” message appears on the instrument panel, accompanied by dashes to indicate that the speed limiter function is activated and waiting to store a limit speed.

To store the current speed, press switch **2** (+): The limit speed will replace the dashes.

The minimum stored speed is 20 mph (30 km/h).

## SPEED LIMITER (2/3)



### Driving

When a limited speed has been stored and this speed is not reached, driving is similar to driving a vehicle without the speed limiter function.

Once you have reached the stored speed, no effort on the accelerator pedal will allow you to exceed the programmed speed except in an emergency (refer to information on “Exceeding the limit speed”).

### Varying the limit speed

The limit speed may be changed by repeatedly pressing:

- switch **2** (+) to increase the speed;
- switch **3** (-) to decrease the speed.

### Exceeding the limit speed

It is possible to exceed the limit speed at any moment. To do this: press the accelerator pedal **firmly and fully** (beyond the resistance point).

Whilst the speed is being exceeded, the cruising speed displayed on the instrument panel flashes.

Then, release the accelerator: the speed limiter function will return as soon as you reach a speed lower than the stored speed.

### Limited speed cannot be maintained

If driving up or down a steep gradient, the system is unable to maintain the limit speed: the stored speed will flash on the instrument panel information display to inform you of this situation.



The speed limiter function is in no way linked to the braking system.

## SPEED LIMITER (3/3)




### Putting the function on standby

The speed limiter function is suspended when you press switch **4** (0). In this case, the limit speed remains stored and the message “SPEED MEMORY” accompanied by this speed appears on the instrument panel.


### Recalling the limit speed

If a speed has been stored, it can be recalled by pressing switch **5** (R).


When the speed limiter is put on standby, pressing switch **2** (+) reactivates the function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.



### Switching off the function

The speed limiter function is deactivated when you press switch **1**. In this case, the speed is no longer stored. The orange instrument panel warning light  goes out, confirming that the function is stopped.

## CRUISE CONTROL (1/4)



The cruise control function helps you to maintain your driving speed at a speed that you choose, called the **cruising speed**.

This cruising speed may be set at any speed above 18 mph (30 km/h).



The cruise control function is in no way linked to the braking system.




This function is an additional driving aid. The function does not take the place of the driver.

Therefore, it can under no circumstances replace the driver's responsibility to respect speed limits and to be vigilant (the driver must always be ready to brake).

Cruise control must not be used in heavy traffic, on undulating or slippery roads (black ice, aquaplaning, gravel) and during bad weather (fog, rain, side winds etc.).


There is a risk of accidents.



### Controls

- 1 Main "On/Off" switch.
- 2 Cruising speed activation, storage and increase switch (+).
- 3 Decreasing cruising speed (-).
- 4 Switch the function to standby (with cruising speed saved) (O).
- 5 Activation with recall of saved cruising speed (R).


## CRUISE CONTROL (2/4)



### Switching on

Press switch **1** side .

Indicator light **6** comes on, lit green, and the message “CRUISE CONTROL” appears on the instrument panel, accompanied by dashes to indicate that the cruise control function is activated and waiting to store a cruising speed.



### Activating cruise control

At a steady speed (above approximately 19 mph (30 km/h)) press switch **2** (+); the function is activated and the current speed is memorised.

The cruising speed replaces the dashes and the cruise control is confirmed by the appearance of a message on the instrument panel and warning light **7** lit green, as well as warning light **6**.



### Driving

Once a cruising speed is memorised and the cruise control function is active, you may lift your foot off the accelerator pedal.

The cruise control switches to standby each time the ECO mode is activated or deactivated. Please refer to the information on “ECO mode function” in Section 2.



Please note that you must keep your feet close to the pedals in order to react in an emergency.

## CRUISE CONTROL (3/4)



### Adjusting the cruising speed

The cruising speed may be changed by pressing the following repeatedly:

- switch **2** (+) to increase the speed,
- switch **3** (-) to decrease the speed.



The cruise control function is in no way linked to the braking system.

### Exceeding the cruising speed

The cruising speed may be exceeded at any time by depressing the accelerator pedal. While it is being exceeded, the cruising speed flashes on the instrument panel.

Then, release the accelerator: after a few seconds, the vehicle will automatically return to its set cruising speed.

### Cruising speed cannot be maintained

When driving down a steep gradient, the system is unable to maintain the cruising speed: the stored speed will flash on the instrument panel information display to inform you of this situation.



## CRUISE CONTROL (4/4)




### Putting the function on standby

The function is set to standby if you:

- the brake pedal;
- move to neutral position;
- switch **4** (O).

In all three cases, the cruising speed is stored.

Standby is confirmed when the green  warning light goes out and the “stored” message appears on the instrument panel.

### Recalling the cruising speed

If a speed has been stored, it can be recalled by pressing button **5** (R), on condition that you are driving faster than approximately 20 mph (30 km/h) and that you are sure that the driving conditions are suitable (traffic, road surface condition, weather conditions, etc.).



**NB:** if the speed previously stored is much higher than the current speed, the vehicle will accelerate more rapidly to reach this threshold.

When the cruise control function is put on standby, pressing switch **2** (+) reactivates the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.



### Switching off the function

The cruise control function is deactivated if you press switch **1**: in this case a speed is no longer stored.

The green  and  indicator lights on the instrument panel go out, confirming that the function is deactivated.



Putting the cruise control on standby or switching it off does not cause a rapid reduction in speed: you must brake by depressing the brake pedal.

## PARKING DISTANCE CONTROL (1/2)

### Operating principle

Ultrasonic sensors in the rear bumper measure the distance between the vehicle and an obstacle.

This measurement is indicated by beeps which become more frequent the closer you come to the obstacle, until they become a continuous beep when the vehicle is approximately 30 centimetres from the obstacle.

**Note:** make sure that the ultrasonic sensors are not obscured (by dirt, mud, snow, condensation etc.).



**Note:** depending on the vehicle, the screen **1** shows the vehicle surroundings alongside the beeps.



### Operation

When reverse gear is selected, most objects which are less than approximately 1.20 metres from the rear of the vehicle are detected, a beep sounds and, depending on the vehicle, the display **1** comes on.




This function is an additional driving aid.

Under no circumstances should it replace the driver's care or responsibility whilst reversing.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

## PARKING DISTANCE CONTROL (2/2)



### Temporary deactivation of the system

(depending on vehicle)

Press switch **2** to deactivate the system:

The indicator light built into the switch lights up to remind you that the system is deactivated.

Pressing the switch again will reactivate the system and switch off the indicator light.

The system is automatically reactivated after the ignition is switched off and the engine restarted.

### Prolonged deactivation of the system

You can deactivate the system permanently by pressing and holding switch **2**.

The warning light built into the switch remains lit constantly.

Pressing the switch again will reactivate the system and switch off the indicator light.




In the event of an impact to the underside of the vehicle (e.g. striking a post, raised kerb or other street furniture) this may result in damage to the vehicle (e.g. twisted axle), the electrical circuit or the traction battery.

To avoid any risk of accident, have your vehicle checked by an approved dealer.

### Operating faults

When the system detects an operating fault, a beep sounds for about 3 seconds as a warning. Consult an approved dealer.

## REVERSING CAMERA (1/2)



### Operation

Moving into reverse gear, the camera **1** located on the rear hinged door provides a view of the area behind the vehicle on the rear-view mirror **2** or, depending on the vehicle, on the multimedia display **3**, accompanied by one or two (moving and fixed) guide lines **4** and **5**.



**Note:** make sure that the reversing camera is not obscured (by dirt, mud, snow, condensation, etc.).




**Note:** depending on the vehicle, you can adjust certain settings from the multimedia display **3**. Refer to the handbook for the equipment.



This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

## REVERSING CAMERA (2/2)



### Dynamic gauge 4 (depending on the vehicle)

This is shown in blue on the multimedia display 3. It indicates the vehicle trajectory according to the position of the steering wheel.

### Static guide line 5:

The fixed clearance gauge comprises coloured markers **A**, **B** and **C**, indicating the distance behind the vehicle:

- **A** (red) approximately 30 centimetres from the vehicle;
- **B** (yellow) approximately 70 centimetres from the vehicle;
- **C** (green) approximately 150 centimetres from the vehicle.

This gauge remains fixed and indicates the vehicle trajectory if the wheels are in line with the vehicle.

This system is initially used with the aid of several gauges (mobile for trajectory and fixed for distance). When the red zone is reached, use the bumper image to stop accurately.

The screen shows a reverse image.

The frames are a representation projected onto flat ground; this information must not be taken into account when superimposed on a vertical object or an object on the ground.

Objects which appear on the edge of the screen may be deformed.

In very bright light (snow, vehicle in sunshine etc.), the camera vision may be adversely affected.


If the rear doors are open or poorly closed, the camera display disappears and, depending on the vehicle, the message "BOOT OPEN" appears.



# Section 3: Your comfort

Air vents: air outlets . . . . .	3.2
Heating, air-conditioning . . . . .	3.4
programming . . . . .	3.8
Additional heating . . . . .	3.10
Air conditioning: information and advice on use . . . . .	3.12
Multimedia equipment . . . . .	3.14
Interior lighting . . . . .	3.15
Sun visor/Mirror . . . . .	3.16
Electric windows . . . . .	3.17
Ashtrays, cigarette lighter, accessories socket . . . . .	3.19
Passenger compartment storage, fittings . . . . .	3.20
Rear bench seat . . . . .	3.24
Transporting objects . . . . .	3.26
in the boot . . . . .	3.26
towing . . . . .	3.27
Roof bars . . . . .	3.28
Spoiler . . . . .	3.28

## AIR VENTS: air outlets (1/2)



42494

1 Demister outlets, side windows.

2 Side air vents.

3 Demisting outlets for the windscreen.

4 Centre air vents.

5 Footwell vents.

6 Control panel



## AIR VENTS: air outlets (2/2)

38504



### Centre air vents

#### Settings

##### Air flow:


Move the control knob **7** (beyond the resistance point).

##### Air distribution:

Right/left: move tabs **8**.

Up/down: guide the air vent up or down.

27088



### Side air vents

#### Settings

##### Air flow:

Move the control knob **10** (beyond the resistance point).

##### Air distribution:

Right/left: move tab **9**.

Up/down: guide the air vent up or down.


To remove bad odours from your vehicles, only use the systems designed for this purpose. Consult an approved Dealer.



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

**There is a risk of damage or of fire.**

## HEATING, AIR-CONDITIONING (1/4)



### The controls

The controls depend on the vehicle equipment.

- 1 - Air recirculation control.
- 2 - Adjusting the air temperature and selecting the heating and air-conditioning programming.
- 3 - Adjusting the ventilation fan speed.
- 4 - Adjusting air distribution in the passenger compartment.

- 5 - Heated rear screen and heated door mirror de-icer and demisting control and warning light.
- 6 - Air conditioning operation control and indicator light (depending on vehicle).
- 7 - Stopping heating. In the stop position, heating no longer uses up any energy.

### Information and advice for use:

Refer to information on "Air conditioning: information and advice on use".

### Switching air conditioning on or off


The air conditioning is switched on (indicator light illuminated) or off (indicator light extinguished) using button 6.

### The air conditioning system is used for:

- lowering the temperature inside the passenger compartment;
- eliminating condensation more quickly.

The air conditioning does not operate when the exterior temperature is low.

## HEATING, AIR-CONDITIONING (2/4)




### Adjusting the air temperature


Turn control **2** to obtain the desired temperature. The further the pointer is away from the heating stop position, the higher the temperature will be.


When the air conditioning system is used for long periods, it may begin to feel cold. To increase the temperature, turn control **2** to the right.


### Distribution of air in the passenger compartment

Turn control **4** to position the pointer opposite the marked positions.


 The air flow is directed to the windscreen demisting vents and the side windows. This position prevents the formation of condensation.

 The air flow is directed to the windscreen demisting vents, the side windows and the passenger footwells. This is the recommended position for the best temperature in cold weather.


 The air flow is directed mainly towards the footwells.

 The air flow is directed to all air vents and the footwells.

This is the recommended position for the best temperature in hot weather.


 The air flow is directed mainly to the dashboard vents.

### Rapid demisting

Turn the controls to the positions :

- air from the outside;
- maximum temperature;
- demisting.

Using the climate control increases the speed of demisting.



### Adjusting the ventilation speed

#### Normal use

Turn control **3** to one of the four positions to start the ventilation system and adjust the power.

Select position 1 for minimum ventilation and position 4 for maximum ventilation.

#### Position 0

In this position:

- heating or air conditioning stops automatically even if button **6** is activated and the warning light remains lit;
- the ventilation speed of air in the passenger compartment is zero;
- there is, however, a slight flow of air when the vehicle is moving.

This position should not normally be used.



### Air recirculation (isolation of the passenger compartment)

Turn control **1** towards the air recirculation symbol .

In these conditions air is taken from the passenger compartment and is recirculated, with no air being taken from outside the vehicle.

#### Air recirculation operates as follows:


- isolating the passenger compartment from the outside air (driving in polluted areas, unpleasant odours, etc.);
- bringing the passenger compartment to the desired temperature as quickly as possible.

Prolonged use of this position can lead to condensation forming on the side windows and windscreen and problems due to the use of non-renewed air in the passenger compartment.

We therefore advise you to return to normal mode (external air) as soon as the air recirculation function is no longer required, by turning control **1** again.

In cold weather ( $< 0^{\circ}\text{C}$ ), you are recommended to position the control **3** in air recirculation position and the fan speed control **2** in position 2 or 3 only. This setting enables greater efficiency and lower energy consumption in reaching the passenger compartment ambient temperature.

## AIR CONDITIONING, HEATING: programming (1/2)




### Adjusting the programming

This function enables the electric network (and not the traction battery) to be used under certain conditions, in order to obtain a comfortable temperature prior to using the vehicle.



It triggers the heating in cold weather and the air conditioning in warm weather.

### Operating conditions

- The ignition must be switched off;
  - the battery must be charged more than 90% for the function to be triggered;
  - the vehicle has to be plugged into the mains;
- and
- control **1** must be in position  at **A** to program the air conditioning or at **B** to program the heating or ventilation.


**Note:** depending on the power of the charging terminal, a slight reduction in the charge level is possible when the function is activated.

It is recommended to position control **3** in the air recirculation position and air distribution control **2** in position:

-  in cold weather;
-  in high temperatures.

These settings make it possible to reach a comfortable temperature in the passenger compartment.

## AIR CONDITIONING, HEATING: programming (2/2)




### Setting the start time for the function

- To programme the start time, use buttons **C** and **D** to navigate through the menu until message COMFORT PROG appears.
- hold down button **D** on stalk **5** - the hours flash;
- press button **C** to adjust them;

- hold down button **D** on stalk **5** - the minutes flash;
- press button **C** to adjust them;
- confirm by pressing button **D** on stalk **5**.


The message “COMFORT PROG” and the programmed time are displayed on the instrument panel **4**.

### Activating the function


- With the ignition on, position the control **1** in one of the  positions;
- turn off the ignition. The “COMFORT” message and the programmed time are displayed on the instrument panel for a few seconds;
- plug in your vehicle to a power supply (refer to the information on “Electric vehicle: charging” in section 1).

The function triggers 30 minutes before the programmed time to reach a comfortable temperature.

### Automatically switching off the function

- About 10 minutes after the programmed time;
- if the charging socket is disconnected;
- if control **1** is not in one of the  positions.

## ADDITIONAL HEATING (1/2)




41153

Depending on the vehicle, the additional heating is designed to heat the passenger compartment. Powered by a dedicated fuel tank (please see “Additional heating tank” in Section 1), this increases the comfort level without reducing vehicle range.

Switching on this additional heating deactivates other heating methods and the air-conditioning.

### Conditions of use

- The engine must be running;
- switch **4** must be engaged;
- the ventilation control **2** should not be at position 0;
- the temperature control **1** should not be at the “Heating off” position **3**;
- The fuel level should not be at minimum.




38495

When the fuel reaches the minimum level, a warning light will come on on the instrument panel. After a few minutes of operation, a message on the instrument panel will tell you that the additional heating is switched off.



## ADDITIONAL HEATING (2/2)



### Operating principle

With the engine running, press switch **4**.

The operation cuts out:

- when the ignition is switched off;
- after a few minutes, when the minimum fuel level has been reached.

### Operating fault

If the additional heating does not switch on:

- start the vehicle;
- switch on the heating by pressing switch **4**;
- wait for 5 minutes;
- turn off the heater;
- switch off your vehicle ignition;
- restart the operation 4 or 5 times.

If the additional heating still fails to operate, please contact an authorised dealer.



With the engine running, when you open the driver's door, a message will appear on the instrument panel along with a beep to tell you to switch off the additional heating.



### Warnings concerning the use of additional heating

- Do not operate the additional heating in an enclosed location; exhaust fumes are poisonous.
- Do not park the vehicle or operate the additional heating in locations where flammable material or substances such as grass or leaves can come into contact with a hot exhaust system.
- Do not operate the additional heating when filling the fuel tank.

## AIR CONDITIONING: information and operating instructions (1/2)

### Range

It is normal to notice an increase in energy usage when the air conditioning is operating.

Switch off the system when it is not required.

### Advice for reducing consumption and helping to preserve the environment

Drive with the air vents on and the windows closed.

If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

### Maintenance

Refer to the Maintenance Document for your vehicle for the inspection frequency.

#### Vehicles equipped with mode ECO

Once activated, ECO mode may reduce air conditioning performance. Please refer to the information on "Driving advice, Eco-driving" in Section 2.

### Operating faults

As a general rule, contact your approved Dealer in the event of an operating fault.

- **Reduction in de-icing, demisting or air conditioning performance.**  
This may be caused by the passenger compartment filter cartridge becoming clogged.
- **No cold air is being produced.**  
Check that the controls are set correctly and that the fuses are sound. Otherwise, switch off the system.

Use the air conditioning system regularly, even in cold weather, running it at least once a month for approximately 5 minutes.



**Do not open the refrigerant fluid circuit.** The fluid may damage eyes or skin.

### Presence of water under the vehicle.


After prolonged use of the air conditioning system, it is normal for water to be present under the vehicle. This is caused by condensation.

### Noise

Each time the ignition is switched off, the ventilation will be switched off after about ten seconds.

Below approximately 10°C, with the engine off it is normal to notice cold air enter the passenger compartment via the vents when ventilation has not stopped (refer to the information on "Heating, air conditioning" in section 3). It is recommended to position the ventilation control at 0 in the event of brief stops.


# AIR CONDITIONING: information and operating instructions (2/2)




The refrigerant fluid circuit (of which some components are hermetically sealed) contains fluorinated greenhouse gases.

Depending on the vehicle, you will find the following information on label **A** affixed inside the engine compartment.






The presence and location of the information on label **A** depends on the vehicle.



Do not open the refrigerant fluid circuit. The fluid may damage eyes or skin.



Before performing any action in the engine compartment, the ignition must be switched off (please see the information on “Starting, stopping the engine” in Section 2).


-  Type of refrigerant fluid
-  Type of oil in the air conditioning circuit
-  Inflammable product
-  Consult the driver’s handbook
-  Maintenance

x.xxx kg Quantity of refrigerant fluid present in the vehicle.

GWP xxxxx Global Warming Potential (CO<sub>2</sub> equivalent).


CO<sub>2</sub> eq x.xx t Quantity in weight and in CO<sub>2</sub> equivalent.

## MULTIMEDIA EQUIPMENT




The presence and location of this equipment depends on the vehicle's multimedia equipment.

- 1 Multimedia touchscreen;
- 2 multimedia sockets;
- 3 radio;
- 4 steering column control;
- 5 microphone.



To operate this equipment: please refer to the instructions for the equipment which should be kept with the other vehicle documentation.

# INTERIOR LIGHTING



## Courtesy lights

Pressing switch **1** gives:

- permanent lighting;
- intermittent lighting, which comes on when a door is opened. It goes out when the doors concerned are properly closed;
- immediate switching off.



## Luggage compartment light **2**

Tilt the switch **2** for permanent lighting.

## Special features


Depending on the vehicle, remote unlocking of the doors triggers timed lighting of the passenger compartment. If one of the front or rear doors is opened, the period for which the light is switched on will start again.

Then the courtesy light and the luggage compartment light dim and go out.

The lighting timer will cut out for various reasons:

- if a door has been open for 15 minutes;
- if all the doors have been closed for 15 seconds or 5 minutes, depending on the vehicle;
- when the ignition is switched on.

## SUN VISOR/MIRRORS



### Front sun visor 1.

Lower sun visor 1.

The clip can be used to hold motorway passes, etc..




### Courtesy mirror 2 (passenger side)

If the sun visor is fitted with a courtesy mirror, it has a cover.



When driving, ensure the courtesy mirror cover is closed. Risk of injury.

## ELECTRIC WINDOWS (1/2)



### Electric windows

#### With the ignition on:

- press the switch for the window concerned to lower it to the desired height;
- lift the switch for the window concerned to raise it to the desired height.

#### From the driver's seat

Operate the switches as follows:

- **1** for the driver's side;
- **2** for the front passenger side.



#### From the front passenger seat

Press switch **3**.

Avoid resting any objects against a half-open window: there is a risk the electric windows may be damaged.



#### Driver's responsibility

Never leave your vehicle with the key inside, and with a child, a dependent adult or a pet, even for a short while. They may pose a risk to themselves or to others by starting the engine or activating equipment (such as the gear lever or electric windows). If any part of the body becomes trapped, reverse the direction of the window immediately by pressing the relevant switch.

#### Risk of serious injury.

## ELECTRIC WINDOWS (2/2)

### One-touch electric windows

(depending on vehicle)

The one-touch mode works in addition to the operation of the electric windows described previously.

**It is fitted to the driver's window and is used for lowering only.**

**Briefly press** the switch **1**: the window lowers completely.

Pressing the switch again while the window is moving will stop its movement.

### Impossible to operate the one-touch electric window

The one-touch electric window is equipped with heat protection: if you press the switch for the window more than sixteen consecutive times, it goes into protection mode (locking the window).


You can:

- use the electric window switch briefly and with intervals of approximately 30 seconds;
- with the engine running, the window will be unlocked after approximately 20 minutes of inaction on the electric window switch.

**Note:** if the window detects resistance when closing (e.g.: branch of a tree, etc.) it stops and then lowers again by a few centimetres.



# ASHTRAYS, CIGARETTE LIGHTER, ACCESSORIES SOCKETS



## Removable ashtray 1

This is a removable ashtray which can be placed in the cup holders.

Lift the cover to open.

To empty it, pull the assembly. The ashtray will come out of its housing.

## Cigarette lighter 2

With the ignition on, press it in. It will spring back with a click when it is ready. Pull it out to use.

After use, replace it without pushing it all the way in.

## Accessories sockets

You can use the cigarette lighter socket<sup>2</sup>. It is provided for connecting accessories approved by the Technical Department with a maximum power of 120 Watts (voltage 12 V).

Depending on the 12V battery charge, the accessories socket may stop working.




Connect accessories with a maximum power of 120 Watts only.

When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.


**Fire hazard.**

# PASSENGER COMPARTMENT STORAGE, FITTINGS (1/3)



## Glovebox



To open the glovebox, lift catch **1**.



## Dashboard storage compartment **2**

## Centre console storage compartment **3**


To open, lift cover **4**. It will store a 1.5 litre bottle.



When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged.

There is a risk of burning if hot liquid escapes.

## PASSENGER COMPARTMENT STORAGE, FITTINGS (2/3)




**Front door storage compartments 5**

### **Bottle holders 6**



No object should be placed on the floor (in front of the driver). Such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.



**Front upper cab storage compartment 7**



Ensure that no hard, heavy or pointed objects are placed in the "open" storage compartments in such a way that they may fall onto passengers during sudden turning or braking.



### **Clip 8**

This can be used for storing motorway tickets, cards, etc.

## PASSENGER COMPARTMENT STORAGE, FITTINGS (3/3)



### Clothes hook 9

Depending on the vehicle, a hook may be located on the partition behind the front passenger seat.

For safety reasons, this hook may only be used to hang clothes.

**NB:** the maximum permitted load is 4 kg.



## REAR HEADRESTS



### To raise it

Slide it to the required height.

### To lower it


Pull it towards you and slide it to the required height.

### To remove it

Raise the headrest then press tabs **1** to release it.

### To refit it

Press tab **1** and insert the rods into the holes, with the notches facing forwards.




### Storage position 2

Pull it towards you and lower it completely.

**The fully lowered headrest position is a storage position:** it should not be in this position when a seat is occupied.



The headrest is a safety component; check that it is fitted and in the correct position.




### Child's convertible headrest

If fitted to the vehicle, the child headrest and booster cushion can only be installed on the rear side seats.

For fitting and use, refer to the equipment instructions.

26342

## REAR BENCH SEAT: functions (1/2)



### To fold down the seatback

Before moving the bench seat, make sure the front seats are pushed forward enough, that the rear seat belts are unfastened and that nothing will obstruct the manoeuvre.

Lower the rear headrests to storage position.

Pull lever **1** of the seatback you wish to fold down (on the right or left-hand side of the bench seat), and bring the seatback down.



The configuration of the two-seat bench with the small seatback **A** pulled down, does not allow the central seat to be used as it would be impossible to buckle the seat belt (belt buckles inaccessible).

Before folding down any rear seat, fasten the seat belt buckle of the seat concerned into its corresponding catch.

This will prevent the seat belt becoming trapped when the seat is returned to its position for use.

In all cases, check that the seat belts are operating correctly.



For safety reasons, carry out any adjustments when the vehicle is not being driven.



When moving the rear bench seat, make sure the bench seat anchorage points are clean (they should be free from grit, cloths etc.).

## REAR BENCH SEAT: functions (2/2)



### To raise the seatback

Before raising the seatback, make sure there are no objects (water bottle, tool box etc.) which will prevent it from locking properly.

Raise the seatback and click it into position. Check that it is correctly locked.

Max. weight: 300 kg, evenly distributed.



When refitting the seatback, make sure it is correctly locked.

If using seat covers, make sure they do not prevent the seatback and seat base latches from locking in. Ensure that the seat belts and seat belt fasteners are correctly positioned.

Reposition the headrests.

### Use restriction

It is forbidden to drive with a seatback or a front seat folded down when there is a passenger occupying a rear seat.



For safety reasons, carry out any adjustments when the vehicle is not being driven.

## TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT, TOWING (1/2)

Always position the objects transported so that the largest surface is against:

- The back of the rear bench seat, for normal loading (**A**).

27381



- The front seatbacks with the rear seatbacks folded down, as is the case for maximum loads (example **B**).

27382



Always position the heaviest items directly on the floor.



Always position the heaviest items directly on the floor.

Use the lashing points on the luggage compartment floor, if these are fitted to the vehicle.


The luggage should be loaded in such a way that no items will be thrown forward and strike the occupants if the driver has to brake suddenly.

Fasten the rear seat belts, even if the seats are not occupied.



## TRANSPORTING OBJECTS IN THE LUGGAGE COMPARTMENT, TOWING (2/2)

27313



**Permissible nose weight, maximum permissible towing weight, braked and unbraked:** refer to the information on “Weights” in Section 6.

### **Choice and fitting of towing equipment**

Maximum weight of towing equipment: 23 kg

For fitting and conditions of use, refer to the equipment's fitting instructions.

Please keep these instructions with the rest of the vehicle documentation.

27314




**A** = 831 mm.

Any towing device must not obstruct any lighting component or the number plate when not in use. Towing devices (ball, hook, etc.) which can be removed without tools and retractable objects must be removed or repositioned when they are not in use.

In all cases, you must comply with the regulations of the particular country you are in.

# ROOF BARS/SPOILER

55235



## Accessing the mounting points 1

Open the doors to access the mounting points 1.



If original roof bars, approved by our Technical Department, are supplied with screws, only use these screws for attaching the roof bars to the vehicle.

## Precautions during use

### Handling the tailgate

Before handling the tailgate, check the objects and/or accessories (bike rack, roof box, etc.) fitted to the roof bars: these must be correctly positioned and secured, so as not to hinder the operation of the tailgate.

For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

Refer to the manufacturer's instructions for information on how to fit and use the roof rack bar.

Please keep these instructions with the rest of the vehicle documentation.

**To find out the maximum permissible load on the roof rack, refer to the information on "Weights" in Section 6.**



The attaching of any carrying device (bike rack, luggage box etc.) resting on the spoiler is prohibited. To install a carrying device on your vehicle, contact an Approved Dealer.

# Section 4: Maintenance

Bonnet . . . . .	4.2
Levels . . . . .	4.4
coolant . . . . .	4.4
brake fluid. . . . .	4.5
windscreen washer reservoir . . . . .	4.5
12 volt battery . . . . .	4.6
Tyre pressure. . . . .	4.8
Bodywork maintenance . . . . .	4.10
Interior trim maintenance. . . . .	4.13
	4.1


## BONNET (1/2)




To open the bonnet, pull the handle **1**.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**



### Unlocking the bonnet catch

To open, push tab **2** to the left as you open the bonnet.

### Opening the bonnet

Lift the bonnet, helping it up, and it will rest in position with the help of struts.



Do not press down on the bonnet: there is a risk that the bonnet may accidentally close.



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.

## BONNET (2/2)

### Closing the bonnet

Check that nothing has been left in the engine compartment.

To close the bonnet again, hold the bonnet in the middle and lower it to 30 cm above the closed position, then release it.



Ensure that the bonnet is properly locked.

Check that nothing is preventing the catch from locking (gravel, cloth, etc.).




After carrying out any work in the engine compartment, check that nothing has been left behind (cloth, tools, etc.).

These may damage the engine or cause a fire.



In the event of even a slight impact involving the radiator grille or bonnet, have the bonnet lock checked by an approved dealer as soon as possible.

## LEVELS (1/2)




### Coolant

With the engine switched off and on level ground, the level **when cold** must be between the “MINI” and “MAXI” marks on the coolant reservoir **1** and **2**. Top this level up **when cold** before it reaches the MIN mark.



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.



### Checking intervals

**Check the coolant level regularly** (very severe damage is likely to be caused to the engine if it runs out of coolant).

If the level needs to be topped up, only use products approved by our Technical Department which ensure:


- protection against freezing;
- anticorrosion protection of the cooling system.

### Replacement intervals

Refer to the Maintenance Document for your vehicle.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  label in the engine compartment reminds you of this.

**Risk of injury.**




No operations should be carried out on the cooling circuit when the engine is hot.

**Risk of burns.**

If there is an abnormal or repeated drop in the fluid level, please consult an authorised dealer.

## LEVELS (2/2)



### Brake fluid

This should be checked frequently, and immediately if you notice even the slightest loss in braking efficiency.

The level should be read with the engine switched off and on level ground.

### Level 3

It is normal for the level to drop as the linings become worn, but it should never drop below the “MINI” warning line.

If you wish to check the disc and drum wear yourself, you should obtain the document explaining the checking procedure from our network or from the manufacturer's website.

### Topping up


After any operation on the hydraulic circuit, a specialist must replace the fluid.

Only use fluids approved by our Technical Department (and taken from a sealed container).

### Replacement intervals

Refer to the Maintenance Document for your vehicle.

If there is an abnormal or repeated drop in the fluid level, please consult an authorised dealer.



### Windscreen washer reservoir

### Topping up

- Open cap 4;
- fill until you can see the fluid;
- close the cap.


### Liquid

Screen wash product (product with antifreeze in winter).

### Jets

Use a tool such as a needle to adjust the height of the windscreen washer jets.

## 12 VOLT BATTERY (1/2)



### Maintenance/replacement

Refer to the Maintenance Document for your vehicle.

#### Never open the battery cover 1.

The charge status of the 12V battery can decrease, especially if you use your vehicle:

- when the exterior temperature drops;
- after extended use of energy-consuming devices (radio etc.) with the engine switched off.



For your own safety and for the proper operation of the vehicle's electrical equipment (lights, windscreen wipers, ABS, etc.), any intervention on the secondary 12 V battery (removal, disconnection, etc.) must **categorically** be performed by a specialist professional.

Risk of serious burns or electric shocks.


Respect **categorically** the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a specific type. Please ensure it is replaced with the same type.

Contact an Authorised Dealer.



## 12 VOLT BATTERY (2/2)



### Label A

Observe the indications on the battery:

- 2 naked flames and smoking are forbidden;
- 3 eye protection required;
- 4 keep away from children;
- 5 explosive materials;
- 6 refer to the handbook;
- 7 corrosive materials.




Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.

26613




Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**

## TYRE PRESSURE (1/2)

27192




### Label A

Open the driver's door to read it.

Tyre pressures should be checked when the tyres are cold.

If the tyre pressures cannot be checked when the tyres are **cold**, increase the pressures from **0.2 to 0.3 bar (or 3 PSI)**. **Never deflate a hot tyre.**

A



34701


**B** : tyre pressures for the front wheels (non-motorway).

**C** : tyre pressures for the rear wheels (non-motorway).

**D** : tyre pressures for the front wheels (motorway).

**E** : tyre pressures for the rear wheels (motorway).

### Vehicle fitted with a tyre pressure loss warning system

If under-inflated (puncture, low pressure, etc.), the warning light  lights up on the instrument panel. See “Tyre pressure loss warning” in Section 2.



### Vehicle used fully laden (Maximum Permissible All-up Weight) and towing a trailer

The maximum speed must be limited to **49.6 mph (80 km/h)** and the tyre pressure increased by **0.2 bar**.

Please refer to the information on “Weights” in Section 6.

**Risk of tyre blowouts.**

## TYRE PRESSURES (2/2)

### **Tyre safety and use of snow chains:**

Refer to the information on “Tyres” in Section 5 for the servicing conditions and, depending on the version, the use of chains.



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

**They must: either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an authorised dealer.**

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

**Risk of loss of control of the vehicle.**

## BODYWORK MAINTENANCE (1/3)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the exterior of the vehicle regularly.

Your vehicle has been treated with very effective anti-corrosion products. It is nevertheless subject to various outside influences.

### Corrosive agents in the atmosphere

- atmospheric pollution (built-up and industrial areas),
- saline atmospheres (near the sea, particularly in hot weather),
- seasonal and damp weather conditions (e.g. road salt in winter, water from road cleaners, etc.).

### Minor impacts

#### Abrasive action

Dust and sand in the air, mud, road grit thrown up by other vehicles, etc.

You should take a number of minor precautions in order to safeguard your vehicle against such risks.

### You should

Wash your car frequently, **with the engine off**, with cleaning products recommended by the manufacturer (never use abrasive products). Rinse thoroughly beforehand with a jet:

- spots of tree resin and industrial grime;
  - mud in the wheel arches and underneath the body which forms damp patches;
  - **bird droppings**, which cause a chemical reaction with the paint that **rapidly discolours paintwork and may even cause the paint to peel off**;
- wash the vehicle **immediately** to remove these marks since it is impossible to remove them by polishing;
- salt, particularly in the wheel arches and underneath the body after driving in areas where the roads have been gritted.

Withdraw the vegetable falls (resin, film etc.) from the vehicle regularly.

Observe the vehicle stopping distances when driving on gravelled surfaces to prevent paint damage.

Repair, or have repaired quickly, areas where the paint has been damaged, to prevent corrosion spreading.

Remember to visit the body shop periodically in order to maintain your anti-corrosion warranty. Refer to the Maintenance Document.

Respect local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

If it is necessary to clean mechanical components, hinges, etc., spray them with products approved by our Technical Department to protect them after they have been cleaned.

We have selected special products to care for your vehicle and you can obtain these from the manufacturer's accessory outlets.

## BODYWORK MAINTENANCE (2/3)

### What you should not do

Wash the vehicle in bright sunlight or freezing temperatures.

Do not scrape off mud or dirt without pre-wetting.

Allow dirt to accumulate on the exterior.

Allow rust to form following minor impacts.

Do not use solvents not approved by our Technical Department to remove stains as this could damage the paintwork.

Do not drive in snow or muddy conditions without washing the vehicle, particularly under the wheel arches and body.



Degrease or clean using high-pressure cleaning equipment or by spraying on products not approved by our Technical Department:

- mechanical components (e.g.: engine compartment);
- the wheels (e.g. braking system components such as brake callipers);
- underbody;
- parts with hinges (e.g.: inside the doors);
- painted plastic external fittings (e.g.: bumpers).

Doing this could give rise to corrosion or operational faults.

## BODYWORK MAINTENANCE (3/3)

### Vehicles with a matte paint finish

This type of paint requires certain precautions.

#### Do not do the following

Use wax-based products (polishing).

Rub too hard.

Wash the vehicle in a roller-type car wash.

Wash the vehicle using a high-pressure device.

Attach stickers to the paintwork (risk of leaving marks).



Wash the vehicle using a high-pressure cleaning device.

#### You should do the following

Wash the vehicle by hand using plenty of water, using a soft cloth or a gentle sponge.

### Using a roller type car wash

Return the windscreen wiper stalk to the Park position (refer to the information on the “Windscreen wash, wipe” in Section 1). Check the mounting of external accessories, additional lights and mirrors, and ensure that the wiper blades are secured with adhesive tape. Remove the radio aerial mast if your vehicle is fitted with this equipment.

Remember to remove the tape and refit the antenna after washing.

### Cleaning the headlights, sensors and cameras

Use a soft cloth or cotton wool. If this does not clean them properly, moisten the cloth with soapy water, then wipe clean with a soft damp cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

**Do not use cleaning products containing alcohol or utensils (e.g.: a scraper).**



#### Washing the vehicle

Never wash the engine compartment, the charging connection or the traction battery with a high-pressure jet.

**This risks damaging the electric circuit.**

Never wash the vehicle while it is charging.

**Risk of electric shock and a risk to life.**

## INTERIOR TRIM MAINTENANCE (1/2)

A well-maintained vehicle will last longer. It is therefore recommended to maintain the interior of the vehicle regularly.

A stain should always be dealt with swiftly.

Whatever type of stain is on the trim, use **cold** (or tepid) **soapy water with natural soap**.

**Detergents (washing-up liquid, powdered products, alcohol-based products) should not be used.**

Use a soft cloth.

Rinse and wipe up excess water.

### Multimedia screen

Maintenance of the screen may depend on the type of multimedia equipment. Please refer to the multimedia instructions for further information.

### Glass instrument panel

(e.g. instrument panel, clock, exterior temperature display etc.)

Use a soft cloth (or cotton wool).

If this does not clean them properly, use a soft cloth (or cotton wool) slightly moistened with soapy water and then wipe clean with another soft damp cloth or cotton wool.

Finally, **carefully** dry off with a soft dry cloth.

**Do not use products containing alcohol and/or spray fluids on the area.**

### Seat belts

They must remain clean.

Use products selected by our Technical Department (approved outlets) or warm, soapy water and a sponge and wipe with a dry cloth.

**Detergents or dyes must not be used under any circumstances.**

### Textiles (seats, door trim, etc)

Vacuum-clean the textiles **regularly**.

#### Liquid stain

Use soapy water.

Dab lightly (never rub) with a soft cloth, rinse and remove the excess.

#### Solid or pasty stain

Carefully remove the excess solid or pasty material **immediately** using a spatula (working from the edges to the centre to avoid spreading the stain).

In the case of a liquid stain, clean as indicated.

#### Special instructions for sweets or chewing gum

Fit an ice cube on the stain to solidify it, then proceed as for a solid stain.

For further recommendations for maintaining the interior, and/or for any unsatisfactory results, please see an authorised dealer.

## INTERIOR TRIM MAINTENANCE (2/2)

### Removal/replacing removable equipment originally fitted in the vehicle

If you need to remove equipment in order to clean the passenger compartment (for example, mats), always ensure that they are correctly refitted and are the right way around (the driver's mat should be fitted on the driver's side, etc.) and fit them with the components supplied with the equipment (for example, the driver mat should always be fixed using the pre-fitted mounting components).

With the vehicle stationary, always ensure that nothing will impede driving (anything obstructing the pedals, heel wedged by the mat etc.).

### You should not:

Position objects such as deodorants, scents etc. near air vents as this could damage your dashboard trim.



Using high-pressure cleaning equipment or sprays inside the passenger compartment:

without careful use, this equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.



# Section 5: Practical advice

Puncture . . . . .	5.2
Emergency spare wheel . . . . .	5.2
Tyre inflation kit . . . . .	5.4
Tool kit . . . . .	5.7
Wheels, trim. . . . .	5.8
Changing a wheel . . . . .	5.9
Tyres . . . . .	5.11
Headlights: changing bulbs . . . . .	5.14
Fog lights: changing bulbs. . . . .	5.16
Rear lights: changing bulbs . . . . .	5.17
Indicator lights: changing bulbs . . . . .	5.20
Interior lighting: changing bulbs. . . . .	5.21
Fuses. . . . .	5.22
Wiper blades . . . . .	5.24
Towing, breakdown . . . . .	5.26
Fitting a radio. . . . .	5.29
Accessories . . . . .	5.30
Radio frequency remote control: batteries. . . . .	5.32
Operating faults . . . . .	5.35

## PUNCTURE, EMERGENCY SPARE WHEEL (1/2)

In the event of a puncture, there is either an emergency spare wheel or tyre inflation kit available, depending on the vehicle (refer to the information in the following pages).

### Emergency spare wheel 2


This is stored in cage 4 under the floor at the rear of the vehicle.

#### To access the emergency spare wheel

- Open the tailgate.
- Undo the nut with the wheelbrace 1.
- Detach the cage using handle 3.
- Release the emergency spare wheel.




If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.



#### To store the wheel in the cage

- Make sure the wheel is correctly positioned in the cage, valve facing down.
- Reposition the cage using handle 3 and retighten the nut using spanner 1 to refit the assembly.
- Make sure it is correctly locked.

### Vehicle fitted with a tyre pressure loss warning system


If under-inflated (puncture, low pressure, etc.), the warning light  lights up on the instrument panel. See “Tyre pressure loss warning” in Section 2.

## PUNCTURE, EMERGENCY SPARE WHEEL (2/2)



If the emergency spare wheel has been stored for several years, have it checked by your Dealer to ensure that it is safe to use.

### **Vehicle fitted with an emergency spare wheel that differs from the other wheels:**

- Never fit more than one emergency spare wheel to the same vehicle.
- As the punctured wheel is wider than the emergency spare wheel, the vehicle's ground clearance is reduced.
- Replace the emergency spare wheel as soon as possible with a wheel identical to the original one.
- If wheel bolts are supplied with the emergency spare wheel, it is imperative that they are used and that they are used for the emergency spare wheel only: refer to the label affixed to the emergency spare wheel.
- When this is fitted to the vehicle, which must only be a temporary measure, the driving speed must not exceed the speed indicated on the label on the wheel.
- Fitting an emergency spare wheel may alter the way the vehicle usually runs. Avoid sudden acceleration or deceleration and reduce your speed when cornering.
- If you need to use snow chains, fit the emergency spare wheel to the rear axle and check the tyre pressure.
- The warning light  on the instrument panel flashes for several seconds, then stays on.

## TYRE INFLATION KIT (1/3)

32788



The kit repairs tyres when tread **A** has been damaged by objects smaller than 4 mm. It cannot repair all types of puncture, such as cuts larger than 4 mm, or cuts in tyre sidewall **B**.

Ensure also that the wheel rim is in good condition.

Do not pull out the foreign body causing the puncture if it is still in the tyre.



Do not attempt to use the inflation kit if the tyre has been damaged as a result of driving with a puncture.

You should therefore carefully check the condition of the tyre sidewalls before any operation.

Driving with underinflated, flat or punctured tyres can be dangerous and may make the tyre impossible to repair.

### **This repair is temporary.**

A tyre which has been punctured should always be inspected (and repaired, where possible) as soon as possible by a specialist.

When taking a tyre which has been repaired using this kit to be replaced, you must inform the specialist.

When driving, vibration may be felt due to the presence of the repair product injected into the tyre.



The kit is only approved for inflating the tyres of the vehicle originally equipped with the kit.

It must never be used to inflate the tyres of another vehicle, or any other inflatable object (rubber ring, rubber boat, etc.).

Avoid spillage on skin when handling the repair liquid bottle. If droplets do leak out, rinse them off with plenty of water.

Keep the repair kit away from children.


Do not dispose of the empty bottle in the countryside. Return it to your approved dealer or to a recycling organisation.

The bottle has a limited service life which is indicated on its label. Check the expiry date.

Contact an approved dealer to replace the inflation tube and repair product bottle.

## TYRE INFLATION KIT (2/3)

42172



Depending on the vehicle, in the event of a puncture, please use the kit located in the glovebox.



Before using this kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the handbrake, ask all passengers to leave the vehicle and keep them away from traffic.

### With the engine running and the parking brake applied,

- Disconnect any accessories previously connected to the vehicle's accessories socket;
- refer to the information on the inflation kit compressor and follow the instructions;
- inflate the tyre to the recommended pressure (please refer to the information in the section on "Tyre pressures");
- after a maximum of **15 minutes**, stop inflating and read the pressure (on the pressure gauge **2**).

**Note:** while the bottle is emptying (approximately 30 seconds), the pressure gauge **2** will indicate briefly a pressure of **6 bar**, then the pressure drops;

- Adjust the pressure: to increase it, continue inflation with the kit. To reduce it, press the button **1**.

If a minimum pressure of 1.8 bar is not reached after 15 minutes, repair is not possible; do not drive the vehicle but contact an approved dealer.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

## TYRE INFLATION KIT (3/3)

Once the tyre is correctly inflated, remove the kit: slowly unscrew the inflation end piece to prevent any product spatter and store the container in plastic packaging to prevent product leaks.

- Affix the driving recommendation label to the dashboard where it can easily be seen by the driver;
- put the kit away;
- at the end of this initial inflation operation, air will still escape from the tyre; you must drive a short distance in order to seal the hole;
- start immediately and drive at between 12.4 and 37.2 mph (20 and 60 km/h) in order to distribute the product evenly in the tyre and, after driving for 1.86 miles (3 km), stop and check the pressure;
- if the pressure is greater than 1.3 bar but less than the recommended pressure, re-adjust it (refer to the label affixed to the edge of the driver's door), otherwise contact an approved dealer: repair is not possible.

### Precautions when using the kit:

- the kit should not be operated for more than 15 consecutive minutes;
- the container must be replaced after the first use even if liquid remains inside.



Nothing should be placed around the driver's feet as such objects may slide under the pedals during sudden braking manoeuvres and obstruct their use.




Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.



Following repair with the kit, do not travel further than 120 miles (200 km). In addition, reduce your speed and under no circumstances exceed 48 mph (80 km/h). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this. Depending on the country or local legislation, a tyre repaired with the inflation kit may need to be replaced.

# TOOL KIT



Remove tools or, depending on the vehicle, the tool kit.

## To remove the tool kit 1 from the luggage compartment

Depending on the vehicle, it may be stored behind a flap. Open it. Undo wheel 2 and pull the tool kit towards you.

**To reposition the tool kit** position tool kit pin 4 into housing 3. Make sure the kit is correctly positioned so as to be able to tighten wheel 2.

The tools included in the tool kit depend on the vehicle.



## Hubcap tool 5

To remove the wheel trims.

## Guide bolt 6 (depending on vehicle)

To finish loosening or starting to tighten the wheel bolts.

## Tow eye 7

Refer to the information on the “Towing: breakdown” in Section 5.

## Wheel brace 8

To undo the wheel bolt and the emergency spare wheel cage nut.

## Jack 9

Refer to Section 5 “Changing a wheel”.

## Retaining bolt (depending on vehicle)

After use, reposition it, making sure that it retains all components in the tool kit.




Do not leave the tools unsecured inside the vehicle as they may come loose under braking. After use, check

that the tools are correctly clipped into the vehicle or, depending on the vehicle, into the tool kit, then position it correctly in its housing: risk of injury.

If wheel bolts are supplied in the tool kit, you must use these bolts only for the emergency spare wheel: refer to the label affixed to the emergency spare wheel.

The jack is designed for wheel changing purposes only. Under no circumstances should it be used for carrying out repairs underneath the vehicle or to gain access to the underside of the vehicle.


## WHEELS, TRIM



### Wheel trim 1 (concealed wheel bolts)

Remove it using hubcap tool **2** (located under the tool kit), by pushing the hook into the opening located near the valve (to reach the metal retaining wire located behind the wheel trim).

To refit it, align it with the valve. Push the retaining hooks, starting with side **A** on the valve side, then **B** and **C** and finish with the side opposite the valve **D**.



### Wheel trim 3 (exposed wheel bolts)

To remove it without removing the wheel, press it at the points indicated by the arrows.

Turn it so that the retaining brackets holding it in place behind the wheel bolts are released.

To refit the hubcap, proceed in reverse order.



## CHANGING A WHEEL (1/2)




Switch on the hazard warning lights.

Keep the vehicle away from traffic and on a level surface where it will not slip.

Apply the handbrake and engage position **P**.

Ask all the passengers to leave the vehicle and keep them away from traffic.



If necessary, remove the wheel trim.

Use the wheelbrace **2** to slacken off the wheel bolts. Position it so as to be able to push from above.

Start extending jack **4** by hand, turning the handle.

You **must** put the jack head on the jacking point **1** nearest the affected wheel and, depending on the vehicle, the place marked with a triangle.

Continue tightening to position the baseplate on the ground correctly. Turn handle **3** on the jack to lift the wheel off the ground.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

## CHANGING A WHEEL (2/2)

Undo the bolts and take off the wheel. For vehicles fitted with alloy wheels, use the guide bolt located in the tool kit to finish loosening and start tightening the bolts.

Fit the emergency spare wheel on the central hub and turn it to align the mounting holes in the wheel and the hub.

Tighten the bolts and lower the jack.

If bolts are supplied with the emergency spare wheel, only use these bolts for the emergency spare wheel.

Tighten the bolts, checking that the wheel is correctly positioned on its hub and unscrew the jack.

With the wheels on the ground, tighten the bolts fully and check they are tight as quickly as possible.

### **Anti-theft bolts**

If you use anti-theft bolts, fit these nearest the valve (wheel trim may not be able to fit).



If you have a puncture, replace the wheel as soon as possible.

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist.

## TYRES (1/3)

The tyres are the only contact between the vehicle and the road, so it is essential to keep them in good condition. You must make sure that your tyres conform to local road traffic regulations.



### Maintaining the tyres

The tyres must be in good condition and the tread form must have sufficient depth; tyres approved by our Technical Department have tread wear indicators **1** which are **indicators moulded into the tread at several points.**

When the tyre tread has been eroded to the level of the warning strips, **they become visible 2**: it is **then** necessary to replace your tyres because the tread profile is no more **than 1.6 mm deep and this causes poor road holding on wet roads.**

An overloaded vehicle, long journeys by motorway, particularly in very hot weather, or continual driving on poorly surfaced minor roads will lead to more rapid tyre wear and affect safety.



Incidents which occur when driving, such as striking the kerb, may damage the tyres and wheel rims, and could also lead to misalignment of the front or rear axle geometry. In this case, have the condition of these checked by an approved dealer.

## TYRES (2/3)

### Tyre pressures

Respect the tyre pressures (including the emergency spare wheel). Check them at least once a month and before a long journey (refer to the label on the edge of the driver's door).

Please refer to the information on "Tyre pressures" in Section 4.



#### **Incorrect tyre pressures**

lead to abnormal tyre wear and unusually hot running.

These are factors which may seriously affect safety and lead to:

- poor road holding;
- risk of bursting or tread separation.

The pressure depends on the load and the speed of use. Adjust the pressures according to the conditions of use (refer to the information on "Tyre pressures").

Pressures should be checked when the tyres are cold; ignore higher pressures which may be reached in hot weather or following a fast journey.

If tyre pressures cannot be checked when the tyres are **cold**, the normal pressures must be increased by **0.2** to **0.3 bar (or 3 PSI)**.

**Never deflate a hot tyre.**



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and lead to pressure loss.

Always use valve caps identical to those fitted originally and tighten them fully.

### Fitting new tyres



For your safety, please respect the speed limit.

When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

**They must: either have a load capacity and a speed capacity at least equal to the original tyres, or correspond to those recommended by your authorised dealer.**

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

**Risk of loss of control of the vehicle.**

## TYRES (3/3)

### Changing wheels around

This practice is not recommended.

### Emergency spare wheel

Refer to the information on the “Emergency spare wheel” and instructions on “Changing a wheel” in Section 5.

### Use in winter

#### – Chains

**For safety reasons, fitting snow chains to the rear axle is strictly forbidden.**

**Chains must not be fitted** to tyres which are larger than those originally fitted to the vehicle.



Chains may only be fitted to tyres of the same size as those originally fitted to **your vehicle.**

Only certain chains can be fitted to tyres. Consult an approved Dealer.

#### – Snow or winter tyres

We would recommend that these be fitted to **all four wheels** to ensure that your vehicle retains maximum grip.

**Note:** be aware that these tyres may sometimes have:

- a direction of travel;
- a maximum speed index which may be lower than the maximum speed of your vehicle.

#### – Studded tyres

This type of equipment may only be used for a limited period and as laid down by local legislation.

It is necessary to observe the speed specified by current legislation.


These tyres must, at a minimum, be fitted to the two front wheels.

**Note:** the use of snow tyres, winter tyres or studded tyres significantly reduces the vehicle range.

In all cases, we would recommend that you contact an approved dealer who will be able to advise you on the choice of equipment which is most suitable for your vehicle.

# HEADLIGHTS : changing bulbs (1/2)

38465



## Dipped beam/main beam headlights

Open the cover **1**.


Disconnect the bulb holder wiring **2**.

Unclip spring **3** to remove the bulb holder **2**.



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.

38472



## Bulb type: H4

It is essential to use 55W anti UV bulbs to prevent damage to the lights' plastic glass.

## Do not touch the bulb glass. Hold it by its base.

To refit it, carry out the above operations in reverse order.

Make sure you reposition the wiring in its housing before closing the cover **1**.

## Front side light

Open the cover **1**.

Disconnect the bulb holder wiring **4**.

Remove bulb holder **4** from its housing. Replace the bulb.

## Bulb type: W5W

To refit it, carry out the above operations in reverse order.




The bulbs are under pressure and can break when replaced.

Risk of injury.




Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**

## HEADLIGHTS : changing bulbs (2/2)

38465



### Direction indicator lights

Turn the bulb holder **5** to release it and remove it from its location without disconnecting the wiring. Replace the bulb.

#### **Bulb type: PY21W**

To refit it, carry out the above operations in reverse order.

To comply with local legislation, or as a precaution, you can obtain an emergency kit containing a set of spare bulbs and fuses from an approved Dealer.



The bulbs are under pressure and can break when replaced.  
Risk of injury.

## FOG LIGHTS: changing bulbs



### Front fog lights 1

As it is necessary to remove parts or components (front bumper), **you are advised to have your bulbs replaced by an approved dealer.**

**Bulb type: H16**



The bulbs are under pressure and can break when replaced.


Risk of injury.

### Additional lights

If you wish to fit your car with fog lights or long range headlights, contact an authorised dealer.



Please note when working close to the engine that it may be hot. The engine cooling fan may also start

at any moment. The  warning light in the engine compartment reminds you of this.

**Risk of injury.**



Any operation on (or modification to) the electrical system must be performed by an approved dealer since an incorrect connection might damage the electrical equipment (harness, components and in particular the alternator). In addition, your Dealer has all the parts required for fitting these units.




### Rear fog lights 2

As it is necessary to remove parts or components (rear bumper), **you are advised to have your bulbs replaced by an approved dealer.**

**Bulb type: P21 W**



## REAR LIGHTS: changing bulbs (1/3)



### Rear lights


Depending on the vehicle, open the hinged doors or the tailgate.

Undo bolts **1** using a Torx tool.

Unclip the lower section, then the upper section of the light by pulling it towards you.

Pull tabs **2** to unclip bulb holders **3**.

Replace the bulb, then proceed in the reverse order to refit the bulb.



### Bulb type

#### 4 Indicator


Pear-shaped, bayonet type bulb **P Y21W**.

#### 5 Side and brake light

Pear-shaped, bayonet type bulb with two filaments **P 21/5W**.

#### 6 Reversing light

Pear-shaped, bayonet type bulb **P 21W**.



The bulbs are under pressure and can break when replaced.

Risk of injury.


## REAR LIGHTS: changing bulbs (2/3)



### High-level brake light

- **Version with tailgate:** it is located above the rear screen, in the centre.
- **Version with hinged doors:** it is located above the rear screen, on the left-hand door.

27514



Remove the two plastic blanking covers **7** from the inside. Unclip the light using a screwdriver, by pressing in the metal clip housings.


Remove light **8** from the outside. Replace the bulb without disconnecting the wiring.

### Bulb type: W16W

For refitting, proceed in the reverse order to removal.

Check the tabs are correctly locked in position.

34843



## REAR LIGHTS: changing bulbs (3/3)



### Number plate light

Undo two bolts **9** using a Torx tool.




Release the light **10** to access bulbs.


**Bulb type: W5W.**

Replace the bulbs, then fit the light in position.

## INDICATOR LIGHTS: changing bulbs



Unclip indicator light **1** on the door side, using a flat-blade screwdriver type tool.



Turn the bulb holder **2** a quarter of a turn and take out the bulb.

**Bulb type: WY5W.**

Replace the bulb and refit the indicator light.

## INTERIOR LIGHTING: changing bulbs



### Passenger compartment lights

Remove the lens **1** using a tool such as a flat-blade screwdriver.



Pull the bulb **2** to remove it from its housing.

**Bulb type 2: W6W**  
**Rear courtesy light bulb type: W6W**

Replace the bulbs and replace the lens.



### Light 3


Remove the lens using a tool such as a flat-blade screwdriver.

Pull the bulb to remove it from its housing.

**Bulb type 3 : W6W**

Replace the bulb and refit the lens.


## FUSES (1/2)



### Fuse box

If any electrical component does not work, check the condition of the fuses.

Unclip cover **A**.



### Tweezers 1

Remove the fuse using tweezers **1**, located at the back of cover **A**.

To remove the fuse from the tweezers, slide the fuse to the side.



Check the fuse in question and **replace it, if necessary, with a fuse of the same rating.**

If a fuse is fitted where the rating is too high, it may cause the electrical circuit to overheat (risk of fire) in the event of an item of equipment using an excessive amount of current.

To locate the fuses, please see the following page.


It is not advisable to use the free fuse locations.

Some functions are protected by fuses located in the engine compartment. However, because of their reduced accessibility, **it is recommended to have these fuses replaced by an authorised dealer.**

To comply with local legislation, or as a precaution, you can obtain an emergency kit containing a set of spare bulbs and fuses from an approved Dealer.

## FUSES (2/2)

42558





### Allocation of fuses

The presence of certain fuses depends on the vehicle equipment level.

Number	Allocation
1	Not used
2	Not used
3	Air conditioning, pedestrian horn
4	heating, traction battery
5	Rear windscreen wiper
6	Horn, diagnostic socket
7	Heated seats, telematic box
8	Traction battery
9	Passenger compartment ECU
10	Windscreen washer
11	Brake lights
12	Passenger compartment ECU
13	Electric window, ECO mode
14	Heated rear screen
15	Starter

Number	Allocation
16	Brake lights, additional equipment, ABS, ESP, luggage compartment light, courtesy light, rain and light sensor
17	Radio, navigation system, display, alarm
18	Additional equipment
19	Heated door mirrors
20	Hazard lights, rear fog lights
21	Central locking of opening elements
22	Instrument panel
23	Not used
24	Radio, heated seats, brake lights
25	Front accessories socket
26	Towbar
27	Electric front windows
28	Rear-view mirror control
29	Passenger compartment motor-driven fan assembly

## WINDSCREEN WIPER BLADES (1/2)



### Replacing windscreen wiper blades 2

- With the ignition switched off, lift wiper arm **2** slightly;
- pull tab **1** upwards;
- move the blade in the direction of the arrow.

For refitting, proceed in the reverse order and ensure that the blade is correctly clipped on.

Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades, windscreen and rear screen regularly with soapy water;
- do not use them when the windscreen or rear screen are dry;
- free them from the windscreen or rear screen when they have not been used for a long time.




Before changing the wiper blade, make sure the stalk is in the stop position (deactivated).

**Risk of injury.**



## WINDSCREEN WIPER BLADES (2/2)



### Replacing the rear screen wiper blade

- With the ignition switched off, lift wiper arm **5**;
- pivot the blade **3**;
- press tab **4**;
- pull the blade to release it (arrow).

For refitting, proceed in the reverse order and ensure that the blade is correctly clipped on.



- In frosty weather, make sure that the wiper blades are not stuck by ice (to avoid the risk of the motor overheating).
- Check the condition of the wiper blades.  
Replace the wiper blades as soon as they begin to lose efficiency (approximately once a year).

Whilst changing the blade, take care not to drop the arm onto the window after it has been removed as this may break the window.

## TOWING, BREAKDOWN (1/3)

### Choice of breakdown service


#### In the event of an energy fault

In the event of a fully discharged traction battery, any type of towing is permitted: **towing on a flatbed truck** or **towing on the road** using the tow eye (please see following pages).

#### All other cases

**Only towing on a flatbed truck is permitted.**

33442




### Towing on a flatbed truck

Breakdown recovery **must** be performed on a flat surface under all circumstances except where the vehicle is immobilised following a full discharge of the traction battery. In the event of a total energy loss, please see the following pages.

Before repairs, insert the key in the ignition to unlock the steering column. Turn the key to position **M**.


The regulations in force for breakdown recovery must always be observed.

## TOWING, BREAKDOWN (2/3)



### In the event of an energy fault: towing

In the event of a fully discharged traction battery:

- the warning light  flashes;
- needle 1 is in the lower section of the reserve zone.

It is possible to recover on a flatbed truck or tow the vehicle using the tow eye, following the instructions below.




When the engine is stopped, steering and braking assistance are not operational.



Before towing, insert the key in the switch to unlock the steering column. Turn the key to position **M**.

The column is unlocked, the accessory functions are supplied: the vehicle lights can be used (hazard warning lights, brake lights etc.). The towed vehicle's lights must be switched on at night.

The speed specified by current legislation for towing must always be observed.




Bring lever to position **N**.

If the lever is stuck in **P**, even though you are depressing the brake pedal, the lever can be released manually.

To do this, unclip the cover at the base of the lever.

Press simultaneously on mark **2** and on the unlocking button on the lever.

## TOWING, BREAKDOWN (3/3)




### Access to towing points

Unclip cover **3** or **5**.

**Tighten the towing hitch **4** fully:** first by hand until it stops then finish by locking it with the wheel brace.

Towing hitch **4** and wheelbrace are located in the tool kit in the luggage compartment (refer to the "Tool kit" information in section 5).



**Only use the front and rear towing points** (never use the driveshafts). These towing points may only be used for towing; never use them for lifting the vehicle directly or indirectly.



Do not remove the key from the ignition when the vehicle is being towed.



Ensure that the towing eye is bolted correctly.

**Risk of losing the towed object.**



Do not leave the tools unsecured inside the vehicle as they may come loose under braking.

After use, check that all the tools are correctly clipped into the tool kit, then, depending on the vehicle, position it correctly in its housing.

**Risk of injury.**

# FITTED AUDIO EQUIPMENT




If your vehicle is not fitted with an audio system, one can be fitted and locations have been provided for:

- radio **1**;
- bass speakers **2**.

To install any equipment, please consult an approved dealer.

## Radio location 1

Unclip the blanking cover. The aerial, + and – supply and speaker wire connections are located behind it.



- In all cases, it is very important to follow the manufacturer's instructions carefully.
- The specifications of the brackets and wires (available from our network) vary depending on the equipment level of your vehicle and the type of radio.  
Consult an approved Dealer to find out the correct part number.
- No work may be carried out on the vehicle's electrical or radio circuits, except by approved dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

## ACCESSORIES (1/2)



### **Electrical and electronic accessories**

Before installing this type of accessory (particularly for transmitters/receivers: frequency bandwidth, power level, position of the aerial, etc.), make sure it is compatible with your vehicle. You can get advice from an authorised dealer.

To install an accessory requiring intervention with the vehicle's 12V electrical circuit, please follow these instructions:

- disconnect the charging cord from the traction battery;
- switch off the ignition;
- disconnect the 12V battery.

#### **Risk of serious injury.**

Before connecting an accessory to a socket, please ensure that it does not exceed the maximum power authorised for the socket. For more information, please refer to the "Multimedia equipment" and "Ashtrays, cigarette lighter, accessories sockets" information in Section 3.

#### **Fire hazard.**

No work may be carried out on the vehicle's electrical or radio circuits, except by authorised dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

If the vehicle is fitted with any aftermarket electrical equipment, make sure that the installation is correctly protected by a fuse. Establish the rating and position of this fuse.

## ACCESSORIES (2/2)



### Using the diagnostic socket

The use of electronic accessories on the diagnostic socket may cause serious disturbance to the vehicle's electronic systems. For your safety we recommend that you use only electronic accessories approved by the manufacturer, consult an Approved Dealer. **Serious accident risk.**

### Use of transmission/receiving devices (telephones, CB equipment etc.).

Telephones and CB equipment with integrated aerials may cause interference to the electronic systems originally fitted to the vehicle: it is advisable only to use equipment with an external aerial. **Furthermore, we remind you of the need to conform to the legislation in force concerning the use of such equipment.**

### Fitting after-market accessories

If you wish to install accessories on the vehicle: please contact an authorised dealer. Also, to ensure the correct operation of your vehicle, and to avoid any risk to your safety, we recommend that you use only accessories specifically designed for your vehicle, which are the only accessories for which the manufacturer will provide a warranty.


If you are using an anti-theft device, only attach it to the brake pedal.

### Obstructions to the driver

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals**

## RADIO FREQUENCY REMOTE CONTROL: batteries (1/2)

27346




### Replacing the remote control battery

Undo screw **1** to remove the remote control cover.



If they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).

27347



Replace battery **2** according to the direction marked on the cover.

Ensure that the cover is correctly clipped on and the screw tightened.

**Note:** It is not advisable to touch the electronic circuit in the key cover when replacing the battery.

The batteries are available from approved Dealers, and their service life approximately two years.

Check that there is no dye on the battery: risk of an incorrect electrical contact.



When replacing:  
– make sure that the batteries are correctly inserted.

**There is a risk of explosion.**

– if the flap does not close correctly, do not use and keep out of reach of children.



## RADIO FREQUENCY REMOTE CONTROL: batteries (2/2)

### Operating faults

If the battery is too weak to ensure correct operation, you can still start and lock/unlock the vehicle (please refer to the information on "Locking/unlocking the doors" in Section 1).

26613



Do not throw away your used batteries; give them to an organisation responsible for collecting and recycling batteries.



### Precautions relating to batteries:

- keep (new or used) batteries out of reach of children;
  - not to swallow the batteries.
- Risk of chemical burns which may led to death.**
- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

## OPERATING FAULTS (1/6)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

Using the remote control	POSSIBLE CAUSES	ACTION REQUIRED
The remote control does not lock or unlock the doors.	The remote control battery is flat.	Use the emergency key.
	Use of appliances operating on the same frequency as the remote control (mobile phone, etc.).	Stop using the devices or use the key.
	Vehicle located in a high electromagnetic radiation zone. Discharged battery.	Replace the battery. You will still be able to lock, unlock, and start your vehicle. If needed, please refer to the information on "Starting, stopping the engine" in Section 2.
	The vehicle is started.	With the engine running, the key's locking/unlocking device is blocked. Turn off the ignition.
	Desynchronisation of the remote control.	Unlock the driver's door using the key in the door lock, then start the engine to synchronise the remote control.

## OPERATING FAULTS (2/6)

The following advice will enable you to carry out quick, temporary repairs. For safety reasons, you should always contact an approved Dealer as soon as possible.

FAULTS	POSSIBLE CAUSES	WHAT TO DO
Impossible to charge the traction battery.	No electrical current in domestic sockets or poor connection of cable to domestic socket.	Check your installation (circuit breaker, programmer, etc.). Check the connections (charging socket etc.). Please refer to "Electric vehicle: charging" in Section 1.
	The outdoor temperature is lower than -26°C.	Recharge your vehicle in a more suitable environment. If necessary, refer to the paragraph on "Towing, breakdown" in Section 5.
	The cord is defective.	Please see an authorised dealer to replace it.

## OPERATING FAULTS (3/6)

FAULTS	POSSIBLE CAUSES	WHAT TO DO
The additional heating does not work.	Fill up the fuel tank.	Top up the tank. See the “Additional heating tank” paragraph in Section 1.
The programmable heating does not work.	One of the usage conditions is not complied with (the traction battery is not charged, etc.).	See information on “Heating, air conditioning: programming” in Section 3.
	The vehicle clock is poorly adjusted or not adjusted.	Adjust the clock on the instrument panel – see the information on “Clock and exterior temperature” in Section 1.

## OPERATING FAULTS (4/6)

On the road	POSSIBLE CAUSES	WHAT TO DO
Steering becomes heavy.	Assistance overheating.	Drive carefully at reduced speed, be aware of the level of force in the steering wheel needed to turn the wheels.
	Fault with the electric assistance motor. Fault in the assistance system	
Vibrations.	Tyres not inflated to the correct pressure, incorrectly balanced or damaged.	Check tyre pressures. If this is not the problem, have them checked by an authorised dealer.
	Coolant leaks.	Check the coolant reservoir: it should contain fluid. If there is no coolant, consult an authorised dealer as soon as possible.

## OPERATING FAULTS (5/6)

<b>Electrical equipment</b>	<b>POSSIBLE CAUSES</b>	<b>WHAT TO DO</b>
The wipers do not work.	Wiper blades stuck.	Free the blades before using the wipers.
	Faulty electrical circuit.	Consult an approved Dealer.
	Fuse damaged.	Replace the fuse (see information on “Fuses” in Section 5).
The wiper does not stop.	Faulty electrical controls.	Consult an approved Dealer.
Direction indicators flashing more quickly.	Blown bulb.	Replace the bulb.
The direction indicators do not work.	Faulty electrical circuit.	Consult an approved Dealer.
	Fuse damaged.	Replace the fuse (see information on “Fuses” in Section 5).

## OPERATING FAULTS (6/6)

Electrical equipment	POSSIBLE CAUSES	WHAT TO DO
The headlights do not switch on or off.	Faulty electrical circuit or control.	Consult an approved Dealer.
	Fuse damaged.	Replace the fuse (see information on "Fuses" in Section 5).
Traces of condensation in the headlights or rear lights.	Traces of condensation may be a natural phenomenon caused by variations in temperature and humidity. In this case, the traces will disappear slowly once the lights are switched on.	







# ***Section 6: Technical specifications***

Vehicle identification plates . . . . .	6.2
Technical Information for the emergency services . . . . .	6.3
Engine identification . . . . .	6.4
Engine specification. . . . .	6.4
Dimensions . . . . .	6.5
Weights . . . . .	6.7
Replacement parts and repairs . . . . .	6.8
Service sheets . . . . .	6.9
Anticorrosion check . . . . .	6.15
	6.1

# VEHICLE IDENTIFICATION PLATES




The information shown on the vehicle identification plate should be quoted on all correspondence or orders.

## Vehicle identification plate A


- 1 Manufacturer name.
- 2 EC design number or approval number.
- 3 Identification number.  
**Depending on the vehicle, this information is also given on marking B.**
- 4 MAM (Maximum Authorised Mass).

- 5 GTW (Gross train weight: vehicle fully loaded, with trailer).
- 6 MPAW (Maximum Permissible Weight) for front axle.
- 7 MPAW on rear axle.
- 8 Reserved for related or additional entries.
- 9 Paint reference (colour code).



## TECHNICAL INFORMATION FOR THE EMERGENCY SERVICES


57157



The QR Code on the **A** label allows emergency workers using a tablet or smartphone to immediately access the technical information useful for working on the vehicle in the event of an accident.

**Note:** on versions not fitted with a rear window, the **A** label is only present on the windscreen at the front.

57329




Ensure that the **A** label is always visible and present on the windscreen as well as the rear screen.

**Any modification or damage would prevent access to the information.**

# ENGINE IDENTIFICATION, ENGINE SPECIFICATIONS

33293




## Engine identification plate

Please quote the engine identification information in area *A* in all correspondence or orders.

(Location varies depending on engine)




- 1 Engine type.
- 2 Engine suffix.
- 3 Engine serial number.



## Engine specification

Engine type 1: 5AM

# DIMENSIONS (in metres) (1/2)



## DIMENSIONS (in metres) (2/2)

	2 seater		5 seater
	Medium	Long	
<b>A</b>	0,9		
<b>B</b>	2.7	3,1	
<b>C</b>	0.7		
<b>D</b>	4,3	4,7	
<b>E</b>	2.1		
<b>F</b>	1.5		
<b>G</b>	1.5		
<b>H (unladen)</b>	1.8		

<b>Turning circles between kerbs</b>	10.7	11.9
<b>Turning circles between walls</b>	11.2	12.4

## WEIGHTS (in kg)

The weights indicated are for a basic vehicle without options: they vary depending on the your vehicle's equipment. Contact an approved Dealer.

	Medium	long
<b>Maximum permissible all-up weight (MMAC) Total train weight (MTR)</b>	Weights are indicated on the vehicle identification plate (refer to the information on "Vehicle identification plates" in Section 6)	
<b>Braked Trailer Weight *</b>	found by calculating: <b>MTR - MMAC</b>	
<b>Unbraked trailer weight *</b>	374	322
<b>Permissible nose weight *</b>	75	
<b>Maximum permissible load on roof</b>	80 (including the carrying device)	

**\* Towing weight (Towing a caravan, boat, etc.)**

Towing is prohibited when the GTW - MAM calculation is equal to zero, or when the GTW is equal to zero (or is not listed) on the identification plate.

It is important to respect local towing regulations in force, specifically those set out in the Highway Code. Contact an approved Dealer for any modifications to towing equipment.

## REPLACEMENT PARTS AND REPAIRS

Original parts are based on strict specifications and are subject to highly-specialised tests. Therefore, they are of at least the same level of quality as the parts fitted originally.

If you always fit genuine replacement parts to your vehicle, you will ensure that it performs well. Furthermore, repairs carried out within the manufacturer's Network using original parts are guaranteed according to the conditions set out on the reverse of the repair order.



# SERVICE SHEETS (1/6)

VIN: .....

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

# SERVICE SHEETS (2/6)

VIN: .....

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					
Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					
Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

# SERVICE SHEETS (3/6)

VIN: .....

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

# SERVICE SHEETS (4/6)

VIN: .....

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

# SERVICE SHEETS (5/6)

VIN: .....

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

# SERVICE SHEETS (6/6)

VIN: .....

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					




  

Date: _____ Miles (Km): _____		Invoice number: _____		Comments/miscellaneous	
<b>Type of operation:</b>		<b>Stamp</b>			
Service <input type="checkbox"/>					
..... <input type="checkbox"/>					
<b>Anti-corrosion check:</b>					
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>					
*See specific page					

# ANTICORROSION CHECK (1/5)

If the continuation of the warranty is subject to repair, it is indicated below.




**VIN:** .....

Corrosion repair operation to be carried out:		
Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (2/5)

If the continuation of the warranty is subject to repair, it is indicated below.

**VIN:** .....




Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		



# ANTICORROSION CHECK (3/5)

If the continuation of the warranty is subject to repair, it is indicated below.




**VIN:** .....

Corrosion repair operation to be carried out:		
Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (4/5)

If the continuation of the warranty is subject to repair, it is indicated below.




**VIN:** .....

Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		

# ANTICORROSION CHECK (5/5)

If the continuation of the warranty is subject to repair, it is indicated below.

VIN: .....

Corrosion repair operation to be carried out:		
Corrosion repair operation to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		
Repair to be carried out:		
Repair to be carried out:		<b>Stamp</b>
Date of repair:		



# ALPHABETICAL INDEX (1/5)

## 12

12 volt battery	
maintenance .....	4.6 – 4.7
12 volt battery .....	1.2 → 1.7, 4.6 – 4.7

## 400

«400 volt» electrical circuit .....	1.2 → 1.8
-------------------------------------	-----------

## A

ABS .....	2.16 → 2.18
accessories .....	5.30 – 5.31
accessories socket .....	3.19
additional heating	
additional heating fuel tank .....	1.97
additional heating .....	3.10 – 3.11
additional heating fuel .....	1.97
additional heating tank .....	1.97
additional methods of restraint .....	1.47
additional tank capacity .....	1.97
additional tank filling .....	1.97
air bag	
activating the front passenger air bags .....	1.63 → 1.65
deactivating the front passenger air bags .....	1.63 → 1.65
air bag .....	1.41 → 1.47
air conditioning .....	3.4 → 3.7, 3.12 – 3.13
air vents .....	3.2 – 3.3
anti-corrosion check .....	6.15 → 6.19
anti-corrosion protection .....	4.10
anti-lock braking system: ABS .....	2.16 → 2.18
ashtrays .....	3.19
audible and visual signals .....	1.88
automatic locking of the doors while driving .....	1.30

## B

battery (remote control) .....	5.32 – 5.33, 5.33
bonnet .....	4.2 – 4.3
brake fluid .....	4.5
brake lights	
changing bulbs .....	5.17 – 5.18
bulbs	
changing .....	5.14 → 5.21

## C

central door locking .....	1.23
changing a bulb .....	5.14 → 5.16, 5.20 – 5.21
changing a wheel .....	5.9
changing gear .....	2.4 → 2.6
charge meter .....	1.75, 2.7 → 2.9
charging cord .....	1.9 → 1.18, 1.21
charging flap .....	1.8 → 1.18
charging socket .....	1.2 → 1.7, 1.9 → 1.18
child minder mirror .....	3.16
child restraint/seat .....	1.48 – 1.49, 1.51 → 1.55, 1.63 → 1.65
child safety .....	1.19, 1.21, 1.25, 1.48 – 1.49, 1.51 → 1.55, 1.63 → 1.65, 3.17
child seats .....	1.48 – 1.49, 1.51 → 1.55
children .....	1.48 – 1.49
cigar lighter .....	3.19
cleaning:	
inside the vehicle .....	4.13 – 4.14
clock .....	1.86
closing the doors .....	1.24 → 1.27
connected services .....	1.3
control instruments .....	1.74 → 1.82
controls .....	1.66 → 1.69
coolant .....	4.4
courtesy light .....	3.15

## ALPHABETICAL INDEX (2/5)

courtesy mirrors ..... 3.16  
cruise control ..... 2.22 → 2.25

### D

dashboard ..... 1.66 → 1.69  
deadlocking the doors ..... 1.21  
de-icing ..... 3.5  
dimensions ..... 6.5 – 6.6  
display ..... 1.71 → 1.76  
doors ..... 1.24 → 1.30  
driver's position ..... 1.66 → 1.69, 1.71 → 1.73  
driving ..... 2.4 → 2.10, 2.12 → 2.27  
driving position  
    settings ..... 1.37 → 1.40  
driving recommendations ..... 2.7 – 2.8

### E

ECO driving ..... 2.7 – 2.8  
ECO mode ..... 2.7  
«ECO» mode function ..... 2.9  
electric vehicle  
    batteries ..... 1.4  
    charging ..... 1.9 → 1.18  
    driving ..... 1.6, 2.4, 2.7 → 2.9  
    important guidelines ..... 1.8, 1.12  
    noise ..... 1.6  
    vehicle range ..... 2.7 → 2.9  
    electric windows ..... 3.17 – 3.18  
electrical installation ..... 1.12  
electronic stability control: ESC ..... 2.16 → 2.18  
emergency brake assist ..... 2.16 → 2.18  
emergency braking ..... 2.16 → 2.18  
emergency spare wheel ..... 5.2  
energy

charge ..... 1.9 → 1.18  
consumption ..... 1.74 – 1.75  
range ..... 2.7 – 2.8  
recovery ..... 1.75  
saving ..... 2.7, 2.9 – 2.10  
energy consumption ..... 2.7 → 2.10  
energy recovery ..... 2.7  
energy saving ..... 2.7 → 2.10  
engine identification ..... 6.4  
engine specifications ..... 6.4  
environment ..... 2.11  
equipment  
    fitting ..... 3.27  
ESC: electronic stability control ..... 2.16 → 2.18  
external temperature ..... 1.86

### F

faults  
    operating faults ..... 5.35 → 5.39  
fitting a radio ..... 5.29  
fittings ..... 3.20 → 3.22  
fog lights ..... 1.91, 5.16  
front lights  
    changing bulbs ..... 5.14 – 5.15  
front passenger air bag deactivation ..... 1.63 → 1.65  
front seat adjustment ..... 1.34 – 1.35  
front seats  
    adjustment ..... 1.34 – 1.35  
fuel  
    capacity ..... 1.97  
    filling ..... 1.97  
    quality ..... 1.97  
fuel filler cap ..... 1.97  
fuses ..... 5.22 – 5.23

# ALPHABETICAL INDEX (3/5)

## G

gear lever.....2.4 → 2.6  
glove box ..... 3.20

## H

handbrake.....2.6  
hazard warning lights signal ..... 1.88  
headlight beam adjustment ..... 1.92 – 1.93  
headrest.....1.31 → 1.33, 3.23  
heated seats..... 1.34 – 1.35  
heating and air conditioning system ..... 3.12 – 3.13  
heating system .....3.4 → 3.13  
heating, air conditioning: programming ..... 2.8, 2.10, 3.8 – 3.9  
horn ..... 1.88  
horn:  
    flash .....1.88  
    sounding the horn ..... 1.88  
hubcap tool.....5.7

## I

indicators ..... 1.88, 5.15, 5.20  
indicators:  
    direction indicators ..... 5.15, 5.20  
    instrument panel .....1.71 → 1.76  
    instrument panel .....1.71 → 1.85  
    instrument panel messages .....1.77 → 1.85  
    interior lighting:  
        changing bulbs..... 5.21  
interior trim  
    maintenance .....4.13 – 4.14  
Isofix .....1.51 → 1.55

## J

jack ..... 5.7, 5.9

## L

levels:  
    brake fluid ..... 4.5  
    coolant ..... 4.4  
    windscreen washer reservoir ..... 4.5  
lifting the vehicle  
    changing a wheel ..... 5.9 – 5.10  
lighting:  
    interior ..... 3.15  
lights  
    adjustment ..... 1.92 – 1.93  
    changing bulbs..... 5.14 – 5.15  
    fog lights ..... 5.16  
    front..... 5.14 – 5.15  
lights:  
    brake lights ..... 5.17  
    dipped beam headlights..... 1.71, 1.89, 5.14  
    direction indicator lights ..... 1.71  
    direction indicators ..... 1.71, 1.88, 5.17  
    fog lights ..... 1.71, 1.91, 5.16  
    hazard warning ..... 1.88  
    main beam headlights..... 1.71, 1.89 – 1.90  
    number plate lights ..... 5.19  
    reversing lights..... 5.17  
    side lights..... 1.89  
lights-on warning buzzer..... 1.24, 1.90  
locking the doors ..... 1.23, 1.28 – 1.29

## M

maintenance:  
    bodywork .....4.10 → 4.12  
    interior trim ..... 4.13 – 4.14  
    mechanical.....4.2 – 4.3, 6.9 → 6.14  
map reading lights ..... 3.15

# ALPHABETICAL INDEX (4/5)

methods of restraint in addition to the front seat belts.....	
1.41 → 1.45	
methods of restraint in addition to the seat belts...1.41 → 1.47	
multimedia (equipment).....	3.14
multimedia equipment.....	3.14, 5.29
<b>N</b>	
navigation.....	3.14
navigation system.....	3.14
<b>O</b>	
opening the doors.....	1.24 → 1.27
operating faults.....	1.71 → 1.73, 5.35 → 5.39
<b>P</b>	
paint	
maintenance.....	4.10 → 4.12
reference.....	6.2
parking distance control.....	2.26 – 2.27
partition.....	1.36
power-assisted steering.....	1.70
practical advice.....	2.7 → 2.10
presentation of electric vehicle	
batteries.....	1.2 → 1.7
pretensioners.....	1.41
puncture.....	5.7, 5.9
<b>R</b>	
radio.....	3.14, 5.29
radio frequency remote control/key	
use.....	1.19, 1.21
range of the traction battery.....	2.7 – 2.8
rear bench seat.....	3.24 – 3.25
rear lights	
changing bulbs.....	5.17 → 5.19

rear screen	
demisting.....	3.2
rear seats	
functions.....	3.24 – 3.25
rear view camera.....	2.28 – 2.29
rear view mirrors.....	1.87
remote control door locking	
batteries.....	5.32 – 5.33, 5.33
remote control electric door locking.....	1.19, 1.21
replacement parts.....	6.8
reverse gear	
selecting.....	2.4 → 2.6
reversing sensor.....	2.26 – 2.27
roof bars.....	3.28
roof rack	
roof bars.....	3.28
<b>S</b>	
seat belts.....	1.37 → 1.47
see-me-home lighting.....	1.90
service sheets.....	6.9 → 6.14
side indicator lights	
bulb replacement.....	5.20
side protection devices.....	1.46
signals and lights.....	1.89 → 1.91
speed control.....	2.4 → 2.6
speed limiter.....	2.19 → 2.21
spoiler.....	3.28
steering wheel	
adjustment.....	1.70
storage compartment.....	3.20 → 3.22
storage compartments.....	3.20 → 3.22
sun visor.....	3.16, 3.22



# ALPHABETICAL INDEX (5/5)

## T

tailgate .....	1.26 – 1.27, 3.26 – 3.27
tank	
Brake fluid .....	4.5
Coolant .....	4.4
tanks and reservoirs:	
windscreen washer .....	4.5
technical specifications .....	6.2, 6.5 → 6.8
temperature regulation .....	3.12 – 3.13
tool kit .....	5.7
towing	
breakdown .....	5.26 → 5.28
in the event of energy failure .....	5.26 → 5.28
towing hitch .....	5.7, 5.27 – 5.28
towing rings .....	1.51 → 1.53
traction battery	
charging .....	1.9
traction battery .....	1.2 → 1.8
traction battery charge .....	1.9 → 1.18, 1.21
traction control .....	2.16 → 2.18
transporting children ....	1.48 – 1.49, 1.51 → 1.55, 1.63 → 1.65
transporting objects	
in the luggage compartment .....	3.26 – 3.27
trims .....	5.8
trip computer and warning system ..	1.71 → 1.73, 1.79 → 1.85
tyre inflation kit .....	5.4 → 5.6
tyre pressure .....	2.12 → 2.15, 4.8
tyre pressure loss warning .....	2.12 → 2.15
tyre pressures .....	4.8 – 4.9, 5.11 → 5.13
tyres .....	2.12 → 2.15, 4.8, 5.11 → 5.13

## U

unlocking the doors .....	1.28 – 1.29
---------------------------	-------------

## V

vehicle identification .....	6.2
vehicle identification plates .....	6.2
vehicle range .....	2.7 → 2.10
ventilation .....	3.2 → 3.9, 3.12 – 3.13

## W

warning lights .....	1.71 → 1.73, 1.77 – 1.78, 1.84
washing .....	4.10 → 4.12
weights .....	6.7
wheelbrace .....	5.7
wheels (safety) .....	5.11
windscreen de-icing/demisting .....	3.5
windscreen washer .....	1.94 → 1.96, 4.5
windscreen washer/wiper	
replacing blades .....	5.24 – 5.25
wiper blades .....	5.24 – 5.25
wipers .....	1.94 → 1.96







RENAULT S.A.S. SOCIÉTÉ PAR ACTIONS SIMPLIFIÉE AU CAPITAL DE 533 941 113 € /13-15, QUAI LE GALLO  
92100 BOULOGNE-BILLANCOURT R.C.S. NANTERRE 780 129 987 — SIRET 780 129 987 03591 /TÉL. : 0810 40 50 60

NU 1063-16 - 99 91 085 56S - 12/2021 - Edition anglaise



**ES**